Business Gateway User Guide

Release 1.1





Copyright	2
Trademarks	2
Software Notice	2
Hardware Notice	2

CONTENTS

TABLES

FIGURES

ABOUT THIS GUIDE

Introduction	. 37
Organization	. 37
Typographical Conventions	. 38
Customer Support	. 39

1 STARTING WITH ICAD80

11
17
12
12
12
łZ ()
łZ
łZ
łΖ
łΖ
12
12
13
13
13
13
13
13
13
14
14
14
14
15
15
1 5
1 5
1 5
1 6
16
16
1 6

Web Server Management Interface	. 46
Enabled by Default.	. 46
Disabled by Default	. 46

2 USING COMMANDS

Introduction	49
On-Line help	49
Help	49
General Information	49
Specific Information	52
Tab Key and ?	52
CLI Commands	53
Maintenance Commands	53
Debug Commands	53
Entering Commands	54
Syntax of CLI Commands	54
Syntax of Debug and Maintenance Commands	54
Interactive Mode	55
Command Keywords	55
NO	55
ALL	56
Showing Configuration	56
Saving Configuration	61
Auto Run Commands	61

3 USER MANAGEMENT

Introduction	3
User Accounts, Groups and Rights	4
Configuration Main Menu 64	4
Adding a User Account	5
Configuration Requirements	5
Configuration Commands	5
Add User Account	5
Show User Account	6
Adding Group	6
Configuration Requirements	6
Configuration Commands	6
Add Group 60	6
Show Group	6
Configuring User Rights	7
Command Authority	7
Configuration Requirements	7
Configuration Commands	7
Configure User Rights	8
Show User Rights	8
Deleting a User Account	8
Configuration Requirements	8
Configuration Commands	8
Delete User Account Example	8
Deleting a User Group	9
Configuration Requirements	9
Configuration Commands	9
Delete Group Account Example 64	9
Deleting User Rights	9
Configuration Requirements	9
Configuration Commands	9
Delete User Rights Example	0

Password Entry	
Failed Login Attempts	
Change Password Example	
Showing Active Users	
RADIUS Client	
Configuration Requirements	71
Configuration Commands	71
Configure RADIUS Authentication	71
Configure Radius Client	
Show logs	73

4 INTERFACE CONFIGURATION

Introduction	75
Configuring LAN Interface (ath1)	. 75
Configuration Poquiroments	. 70
Configuration Commands	. 70
Configure oth1 Interface	. 70
Show Configuration	. 70
Configuring WAN Interface (ath0)	. 70
Configuration Dequirements	
Configuration Commands	
Configure athound interface	
Configuration	
Configuring T1 Lino	. //
Configuration Doguiroments	. 70
Configuration Requirements	
Configuring T1 Line	
Configuring 11 Line	
Snow Configuration	
Configuration Status	
Snow 11 Alarms	80
Configuring PVC (Frame Relay)	80
Configuration Requirements	80
Constraints	80
Configuration Commands	81
	. 81
Policing Trattic	81
	. 81
PVC Statistics	82
	82
Global Frame Relay	82
Clear Statistics	83
Configuring Local Management Interface	. 83
Configuration Requirements	83
Configuration Commands	83
Show LMI	. 84
Statistics	84
Clear Statistics	85
Configure PVC Interface	. 85
Assigned IP Interface	. 85
Configuring PVC Interface	. 85
Show PVC Interface	. 85
Configuring VLAN	. 86
Configuring VLAN Interface	. 86
Configuration Requirements	. 87
Configuration Commands	. 87
VLAN Interface Configuration	. 87

VLAN IP Address Assignment	
Configure VLAN Interface	87
Example 1	88
Show VLAN Interface	89
Modify VLAN Interface	89
Remove VLAN Interface	

5 SYSTEM CONFIGURATION

Introduction	. 91
Time (SNTP Client)	. 91
Configuration Requirements	. 91
Configuration Commands	. 91
Configure Time	. 91
SNTP Time	. 92
Local Time	. 92
Modify SNTP Time	. 93
Show SNTP Time	. 93
DNS Client	. 93
Configuration Requirements	. 93
Configuration Commands	. 93
Configure DNS Client	. 94
Show DNS Client	. 94
Check DNS Client	. 94
Watchdog	. 95
Configuration Requirements	. 95
Configuration Commands	. 95
Configure Watchdog	. 95
Show Watchdog	. 95
Show System Exceptions	. 95
Show Exceptions Commands	. 95
Show Exceptions	. 96
Hardware	. 96

6 ROUTING CONFIGURATION

Introduction	99
Configuring ARP	99
Configuration Requirements	99
Configuration Commands	99
Configure ARP	100
Show ARP	100
Delete ARP	100
Flush ARP Table	101
Configuring Static Routing	101
Configuration Requirements	101
Configuration Commands	101
Add Static Route	101
Example 1	101
Example 2	101
Show Route Table	102
Delete Static Route	102
Configuration Commands	102
Configuring Dynamic Routing	102
Configuration Requirements	102
Configuration Commands	102
Configure Dynamic Routing	103
Show Dynamic Routing	103
Show Dynamic Route	103

7 SWITCHING CONFIGURATION

Introduction	. 105
Configuring LAN Ports	. 105
Speed	. 106
Duplex mode	. 106
Flow Control	. 106
Default Settings	. 106
Configuration Requirements	. 106
Configuration Commands	. 106
Configure LAN Ports	. 107
Example 1	. 107
Example 2	. 107
Example 3	, 107
Example 4	, 107
Show Configuration	, 107
Show Statistics	. 108
Clear Statistics	, 108
Configuring WAN Port	, 109
Speed	. 109
Duplex mode	, 109
Flow Control	, 109
Default Settings	, 109
Configuration Requirements	, 109
Configuration Commands	, 109
Configure WAN Port	, 110
Show Configuration	, 110
Show Statistics	, 110
Clear Statistics	. 111
Configuring ARL	, 111
Configuration Requirements	. 111
Constraints	. 111
Configuration Commands	. 111
Add ARL	, 113
Show configuration	. 113
Remove ARL	, 113
Flush ARL	. 113
Configuring Port Mirroring	. 114
Limitations and Recommendations	. 114
Configuration Requirements	. 114
Constraints	, 114
Configuration Commands	. 114
Configure Mirroring	. 114
Show Configuration	. 114
Remove Port Mirroring	. 115
Configuring Layer 2 QoS	. 115
Priority Queues	. 115
Configuration Requirements	. 116
Configuration Main Menu	. 116
Configure Layer 2 QoS	. 116
Configuration Commands	. 116
Configuring QoS Type	. 118
Configuring Priority	, 118
Show Configuration	. 118
Configuring VLAN	. 118
Configuration Requirements	. 119
Configuration Commands	. 119
Configure VLAN	. 120

Example 1 1	20
Example 2 1	20
Example 3 1	20
Show VLAN	20
Remove VLAN	21
Configuring STP 1	21
Spanning Tree Protocol (STP)	21
Configuration Requirements	22
Configuration Commands 1	22
STP Settings 1	22
STP Status 1	23
Configure STP 1	24
Show STP 1	24

8 SECURITY CONFIGURATION

Introduction	127
Traffic	127
VPN	128
SA	128
Configuring Firewall (Security Policies)	128
Configuration Requirements	128
Configuration Commands	128
Configure Firewall Rules	129
Show Firewall Rule	130
Remove Firewall Rule	130
Show Logs	130
Connection Timeout	131
Configuration Requirements	131
Configuration Commands	131
Show Timeout	131
Configuring IDS	131
IDS Anomaly	132
IDS Flood	132
IDS Scan	132
IDS Spoof	132
Configuration Parameters	132
Configuring IDS Anomaly	132
Configuring IDS Flood Activity	134
Configuring IDS Flood Settings	134
Configuring IDS Scan	136
Configuring IDS Spoof	136
Show IDS Statistics	137
Clear IDS Statistics	139
Show IDS Logs	139
Configuring NAT	140
Configuration Requirements	140
Configuration Main Menu	140
Configuring NAT Interface	141
Configuration Requirements	141
Configuration Commands — NAT Interface	141
Configure NAT Interface	141
Show Configuration	141
Configuring NAT Policy	141
Configuration Requirements	141
Configuration Commands	141
Configure NAT Policy	142
Configuring NAT Public	143

Configuring ALG14	14
Configuration Requirements14	14
Configuration Commands 14	14
Configure ALG14	14
Show ALG14	45
Security Configuration Using NAT14	45
Port Forwarding14	45
Address Forwarding14	46
Configure Static NAT14	17
Configuring IPsec	47
Configuration Main Menu14	48
Configuring IPsec Policy14	48
Configuration Requirements14	18
Configuration Commands14	18
Configure IPsec Proposal	19
Configuration Requirements14	19
Configuration Commands14	19
Configuring IPsec14	19
Show IPsec Proposal	19
IPsec Statistics	50
Configuring IKE	50
Configuration Main Menu	50
Configuring IKE Policy	51
Configuration Requirements	51
Configuration Commands	51
Configure IKE Policy	51
Show IKE Policy	51
Show IKE SA	52
Configuring IKE Preshared	52
Configuration Requirements	52
Configuration Commands	53
Configure IKE Preshared15	53
Show IKE Auto	53
Show IKE Task	53
V	N Configura-
tions 15	54
Office to Office VPN15	54
Local VPN Tunnel Interface15	54
Tunnel Interface	54
Routing All Traffic	55
Show Configuration	56

9 QOS CONFIGURATION

Introduction	
GoS	
Configuring QoS	
Configuring QoS Links	
Configuration Requirements	
Constraints and Recommendations	
Configuration Commands	
Configure QoS Link	
Show QoS Link	
Remove QoS Link	160
Configuring Quality Groups	
Configuration Requirements	
Configuration Commands	
Quality Guaranteed Class	

Configure Quality Group	161
Example 1	161
Example 2	162
Show Quality Group	162
Remove QoS Group	162
Configuring Traffic Classification	162
Configuration Requirements	162
Configuration Commands	163
Configure Traffic Classification	163
Example 1	163
Example 2	164
Show Traffic Classification	164
Remove Traffic Classification	164
QoS Statistics	164
Cumulative Statistics	164
Show Statistics	164
Clearing Counters	166
Instantaneous Statistics	166

10 SIP CONFIGURATION

Introduction	169
SIP Session Controller	170
SIP User Agent	170
SIP User Agent Features	170
Configuring SIP Server	171
Configuration Requirements	171
Configuration Commands	171
Configure SIP Server (Manual Mode)	172
Configure SIP Server (Automatic Mode)	172
Configure Failover Mode	172
Configure Load Balancing	173
Configure Additional SIP Servers	173
Show Configuration	174
Show Status	176
Configuring SIP Session Controller	176
SIP Signaling Proxy (SSP)	177
Configuration Requirements	177
Configuration Commands	177
Configure SIP Signaling Proxy (SSP)	177
Show Configuration	178
Show Status	178
Show Statistics	179
Media BRidge (MBR)	181
Configuration Requirements	181
Configuration Commands	181
Configure Media BRidge (MBR)	181
Show Configuration	182
Show Status	182
Show Statistics	182
Access Control List (ACL)	183
Configuration Requirements	183
Configuration Commands	183
Configure Access Control List (ACL)	184
Show Configuration	184
Endpoint Status Handling (ESH)	185
Configuration Requirements	185
Endpoint Status Handling (ESH)	185

Show Configuration	185
Show Statistics	185
Call Admission Control (CAC)	186
Configuration Requirements	186
Configuration Commands	186
Configure Call Admission Control (CAC)	186
Voice Quality Monitoring (VQM)	188
Configuration Requirements	188
Configuration Commands	188
Configure Voice Quality Monitoring (VQM)	189
Show Configuration	190
Show Statistics	190
Statistics Voice Quality	191
Alarm Logs	191
Alarms Statistics	192
Configuring SIP User Agent	192
Configuring SIP Protocol	193
Configuration Requirements	193
Configuration Commands	193
Show Configuration	194
Configuring FXS Port	194
Configuration Requirements	194
Configuration Commands	194
Show Configuration	195
Show Statistics	196
Configuring SIP UA	196
Configuration Requirements	197
Configuration Commands	197
Show Configuration	198
Show Status	198
Configure Numbering Plan	199
Configuration Requirements	200
Configuration Commands	200
Show Configuration	201
Show Call Statistics	201
Show Commands	201
Show Current calls	202
Show Call History	202
Configuring SIP Endpoints	203
Access Control List (ACL)	203
Registration	203

11 MGCP CONFIGURATION

Introduction	205
MGCP Session Controller	206
MGCP User Agent	206
Configuring MGCP Server	207
Configuration Requirements	
Configuration Commands	207
Configure MGCP Server	207
Configure Failover Mode	
Show Configuration	208
Show Status	
Configuring MGCP Session Controller	
MGCP Signaling Proxy (MSP)	
Configuration Requirements	
Configuration Commands	

Configure MGCP Signaling Proxy (MSP)	210
Show Configuration	211
Show Status	211
Show Statistics	211
Media BRidge (MBR)	213
Configuration Requirements	213
Configuration Commands	213
Configure Media BRidge (MBR)	214
Show Configuration.	214
Show Status	214
Show Statistics	215
Access Control List (ACL)	215
Configuration Requirements	215
Configuration Commands	215
Configure Access Control List (ACL)	216
Show Configuration	216
Endpoint Status Handling (ESH)	217
Configuration Requirements	217
Configuration Commands	217
Configure Endpoint Status Handling (ESH)	217
Show Configuration	218
Show Statistics	218
Call Admission Control (CAC)	210
Configuration Requirements	219
Configuration Commands	219
Configure Call Admission Control (CAC)	219
Show Configuration	220
Show Status	220
Show Statistics	220
Voice Quality Monitoring (VOM)	221
Configuration Requirements	221
Configuration Commands	221
Configure Voice Quality Monitoring (VOM)	221
Show Configuration	222
Show Statistics	223
Configuring MGCD User Agent	225
	225
Configuration Dequirements	220
Configuration Commands	220
Configuration Configuration	220
Show Cominguration.	220
Configure FAS Port	220
Configuration Requirements	227
Configuration Commanus	227
Configure FAS Port	227
Show Configuration	227
Snow Status	220
	220
	229
Configuration Requirements	230
Configuration Commands	230
Show Configuration	Z31
Snow Status	231
Snow Call Statistics	23Z
Snow Commands	23Z
Snow Current Calls	233
Snow Call History	233
Configuring MGCP Endpoints	234
Access Control List (ACL)	Z34

Registration

12 VOIP SURVIVABILITY

Introduction	
Local Call Routing	
Lifeline Failover	
Local Call Routing	
Configuration Requirements	
Configuration Main Menu	
Configure LCR Accounts	
Configure LCR Settings	
Example 1	
Example 2	
Show Configuration	
Show Status.	
Show Connections	
Lifeline Failover	

13 SERVICES CONFIGURATION

Introduction	243
File System	244
File System Navigation	244
Configuration Requirements	244
Configuration Commands	244
Navigate Through File System	245
File System Management	245
Configuration Requirements	245
Configuration Commands	245
Manage File System	246
SFTP Server	247
Configuration Requirements	247
Configuration Commands	248
DSA Host Keys	248
Configure SFTP	248
Show Configuration	248
Regenerate SFTP keys	249
Upload Public Key	249
Remote Administration Services	250
Telnet Server	250
Configuration Requirements	250
Configuration Commands	250
Configure Telnet	250
Show Configuration	250
Show Connections	250
Telnet Client	250
Configuration Requirements	251
Configuration Commands	251
Open Telnet Session	251
SSH Server	251
Configuration Requirements	251
Configuration Commands	251
DSA Host Keys	252
Configure SSH	252
Show Configuration	252
Regenerate SSH keys	252
Upload Public Key	253
Show Connections	253

Web Server	253
SSL	253
Web Server	257
IP Connectivity Services	259
Ping	259
Ping Options	259
Ping	259
Traceroute	260
Configuration Requirements	260
Traceroute Options	260
Traceroute	260
Services To VoIP Phones	261
DHCP Server	261
Configuration Requirements	261
Configuration Commands	261
Configure DHCP Server	262
Show Configuration	263
Show DHCP Leases	263
DHCP Relay	264
Configuration Requirements	264
Configuration Commands	264
Configure DHCP Relay	264
Show Configuration	264
DNS Relay	264
Configuration Requirements	264
Configuration Commands	265
Configure DNS Relay	265
Show Configuration	265
Show Sessions	265
Show Cache	266
SNTP Relay	266
Configuration Requirements	266
Configuration Commands	266
Configure SNTP Relay	266
Show Configuration	266
Show Sessions	267
TFTP Relay	267
TFTP Relay	267
TFTP Cache	268
Monitoring	
Introduction	271

14

Introduction	. 271
System Status	. 271
System Hardware	. 271
System Information	. 272
System Exceptions	. 272
System Operations	. 273
Audit Logging	. 273
Configuration Requirements	. 273
Configuration Commands	. 273
Configure Audit Logging	. 273
Show Configuration	. 273
Show logs	. 274
Clear logs	. 274
Module Logging	. 274
Logging Level	. 275
Logging Map	. 276

Logging Destination	277
System Summary	279
Network Activity	280
Port Mirroring	280
Port Statistics	280
IP Stack Statistics	280
IP Statistics	280
ICMP Statistics	282
UDP Statistics	283
TCP Statistics	284
Protocol Monitoring (PMON)	286
Configuration Requirements	287
Configuration Commands	287
Configure PMON	287
Show Configuration	288
Show Statistics	288
Clear Statistics	289
Netflow	289
Configuration Requirements	289
Configuration Commands	289
Configure Netflow	290
Show Configuration	291
Show Statistics	291
Clear Statistics	291
SNMP	292
SNMP Agent	292
SNMP Traps	295
trapmib	296
Configuration Requirements	296
Command	296
Example	296
TCPdump	297
Configuration Requirements	297
Start Capture	298
Stop Capture	299
Voice Quality Monitoring	300
Network Discovery	300
Cisco Discovery Protocol (CDP)	300
Configuration Requirements	300
Show Commands	300
Show CDP Entry	300
Show Neighbors	301
Show Statistics	302

A UPGRADE SOFTWARE

Introduction	
Check Boot Code	
Images	
Upgrading Software Via Web UI	
Requirements	
Upgrade Software via Web UI	
Verify Software Installation	
Change Default Application Image	
View Bootloader Code	
Find IP Address via CLI	

	Introduction	311
	Web UI Features	312
	Browser Support	312
	User Interface	312
	Configuration	312
	Monitoring and Tracking	312
	Wizards	312
	WEB UI Navigation	313
	Buttons	313
	Additional Functions and User Modes	313
	i	313
	?	313
	S/A – User Modes	313
	Configuration Menu	315
	Operations	315
	Logout	315
	Save System	315
	Reset System	315
	Logging in to Web UI	316
	Login Requirements	316
	Login to Web UI	316
	Configuring ICAD80	317
	Configuring User Accounts	317
	Monitoring	320
	Using Wizards	321
	Configuring Interface	321
	Upgrading ICAD80 Software	325
	Fxit Weh III	326
c	THIRD PARTY SOFTWARE Software Applications	327
C D	THIRD PARTY SOFTWARE Software Applications SSH FUNCTIONALITY	327
C D	THIRD PARTY SOFTWARE Software Applications	327 329
C D	THIRD PARTY SOFTWARE Software Applications SSH FUNCTIONALITY Introduction SSH Server Functionality	327 329 329
C D	THIRD PARTY SOFTWARE Software Applications SSH FUNCTIONALITY Introduction SSH Server Functionality SFTP	327 329 329 330
C D	THIRD PARTY SOFTWARE Software Applications SSH FUNCTIONALITY IntroductionSSH Server FunctionalitySFTPAuthentication	327 329 329 330 330
C D	THIRD PARTY SOFTWARE Software Applications SSH FUNCTIONALITY IntroductionSSH Server FunctionalitySFTPAuthenticationHost Keys	327 329 329 330 330 330
C D	THIRD PARTY SOFTWARE Software Applications SSH FUNCTIONALITY IntroductionSSH Server FunctionalitySFTPAuthenticationHost Keys	327 329 329 330 330 330 331
C D	THIRD PARTY SOFTWARE Software Applications SSH FUNCTIONALITY Introduction SSH Server Functionality SFTP Authentication Host Keys Remote Login Service Functions	327 329 329 330 330 330 331 331
C D	THIRD PARTY SOFTWARE Software Applications SSH FUNCTIONALITY Introduction SSH Server Functionality SFTP Authentication Host Keys Remote Login Service Functions SSH Service	327 329 329 330 330 330 331 331 331
C D	THIRD PARTY SOFTWARE Software Applications SSH FUNCTIONALITY Introduction. SSH Server Functionality. SFTP. Authentication. Host Keys. Remote Login	327 329 329 330 330 330 331 331 331 331
C D	THIRD PARTY SOFTWARE Software Applications SSH FUNCTIONALITY Introduction SSH Server Functionality SFTP Authentication Host Keys Remote Login Service Functions SSH Service SFTP Service SSH System Architecture	327 329 330 330 331 331 331 331 331
C D	THIRD PARTY SOFTWARE Software Applications SSH FUNCTIONALITY Introduction. SSH Server Functionality. SFTP. Authentication. Host Keys. Remote Login Service Functions SSH Service. SFTP Service SSH System Architecture. SSH-TRANS	327 329 330 330 331 331 331 331 331 332 332
C	THIRD PARTY SOFTWARE Software Applications SSH FUNCTIONALITY Introduction. SSH Server Functionality. SFTP. Authentication. Host Keys Remote Login Service Functions SSH Service. SFTP Service. SSH System Architecture. SSH-TRANS. SSH-AUTH	327 329 330 330 331 331 331 331 332 332 332
C	THIRD PARTY SOFTWARE Software Applications SSH FUNCTIONALITY Introduction. SSH Server Functionality. SFTP. Authentication. Host Keys Remote Login Service Functions SSH Service . SSH Service . SSH System Architecture. SSH-TRANS. SSH-CONNECTION	327 329 330 330 331 331 331 331 332 332 332
C	THIRD PARTY SOFTWARE Software Applications SSH FUNCTIONALITY Introduction. SSH Server Functionality. SFTP. Authentication. Host Keys Remote Login Service Functions SSH Service. SFTP Service. SSH System Architecture. SSH System Architecture. SSH-TRANS. SSH-AUTH. SSH-CONNECTION.	327 329 330 330 331 331 331 331 332 332 332 332
C D	THIRD PARTY SOFTWARE Software Applications SSH FUNCTIONALITY Introduction SSH Server Functionality SFTP Authentication Host Keys Remote Login Service Functions SSH Service SFTP Service SSH System Architecture SSH-TRANS SSH-CONNECTION	327 329 330 330 331 331 331 332 332 332 332
C D	THIRD PARTY SOFTWARE Software Applications SSH FUNCTIONALITY Introduction SSH Server Functionality SFTP Authentication Host Keys Remote Login Service Functions SSH Service SFTP Service SSH System Architecture SSH-TRANS SSH-AUTH SSH-CONNECTION	327 329 330 330 331 331 331 332 332 332 332 332
C D	THIRD PARTY SOFTWARE Software Applications SSH FUNCTIONALITY Introduction SSH Server Functionality SFTP Authentication Host Keys Remote Login Service Functions SSH Service SFTP Service SSH Service SSH Service SSH Service SSH System Architecture SSH-TRANS SSH-CONNECTION CLI COMMANDS Introduction CLI Command Access	327 329 330 330 331 331 331 332 332 332 332 333 333
C D	THIRD PARTY SOFTWARE Software Applications SSH FUNCTIONALITY Introduction SSH Server Functionality SFTP Authentication Host Keys Remote Login Service Functions SSH Service SFTP Service SSH System Architecture. SSH-TRANS SSH-AUTH SSH-CONNECTION	327 329 330 330 331 331 331 332 332 332 332 333 333 333
C D	THIRD PARTY SOFTWARE Software Applications SSH FUNCTIONALITY Introduction SSH Server Functionality SFTP Authentication Host Keys Remote Login Service Functions SSH Service SSH Service SSH Service SSH System Architecture SSH-TRANS SSH-CONNECTION CLI COMMANDS Introduction CLI Command Access CLI Configuration Commands audit	327 329 330 330 331 331 331 332 332 332 333 333 333 333
C D	THIRD PARTY SOFTWARE Software Applications SSH FUNCTIONALITY Introduction SSH Server Functionality SFTP Authentication Host Keys Remote Login Service Functions SSH Service SSH Service SFTP Service SSH System Architecture SSH-TRANS SSH-AUTH SSH-CONNECTION CLI COMMANDS Introduction CLI Command Access CLI Configuration Commands. audit. calls analyser	327 329 330 330 331 331 331 332 332 332 333 333 333 333
C D	THIRD PARTY SOFTWARE Software Applications SSH FUNCTIONALITY Introduction SSH Server Functionality SFTP Authentication Host Keys Remote Login Service Functions SSH Service SFTP Service SSH System Architecture SSH-TRANS SSH-CONNECTION CLI COMMANDS Introduction CLI Command Access CLI Configuration Commands audit. calls analyser connection tcp.	327 329 330 330 331 331 331 332 332 332 333 333 333 333

framer hw	335
ids	335
ids anomaly	336
ids flood activity	336
ids flood settingsj	336
ids scan	336
ids spoof	336
ike	337
ike policy	337
ike preshared	337
interface ip	337
int vlan	338
ipsec	338
ipsec policy	338
ipsec proposal	339
lcr	339
lcr accounts	339
lcr settings	339
logging	340
logging dest	340
logging map	340
logging modules	341
media settings	341
mgcp	341
mgcp sc settings	342
mgcp server settings	342
mgcp ua	342
mgcp ua port	342
mgcp ua settings	343
netflow	343
netflow agent	343
netflow filter	344
pmon	344
pmon agent	344
pmon trace	344
protocol	345
QOS	345
dos group	345
gos link	346
radius client	346
relav	346
relay dns settings	347
relay sntp settings	347
relay tftp cache	347
relay tftp files	348
relay tftp settings.	348
rip daemon	348
route	348
route arp	348
route table	349
security	349
security alg	349
security policy	350
service	351
service ssh	351
service telnet	351
service weh	357
shell terminal	352
Sheet terminat	552

sin	352
sin gateway settings	352
sin sc settings	352
sin server settings	352
sin ua nort	353
sin ua settings	354
sip du securizs	354
snmp agent	355
somo community	355
some trans	355
ccl	355
ssl cert	356
ccl ccr	356
si ci lav	356
switch	357
switch agging	257
switch gos port	357
switch gos sotting	257
switch gos too	220
switch art	220
switch mirror	220
switch mirror	320
switch port	328
vian	359
system	359
system dns	359
system images	359
system info	360
system sntp	360
system startup	360
system watchdog	360
user	361
user accounts	361
user groups	361
voice	362
voice acl	362
voice np	363
voice parameters	363
Show CLI Commands	363
audit	363
audit log	363
audit status	364
calls	364
calls alarms	364
calls analyser	364
calls current	365
calls history	365
calls quality	366
calls statistics	366
cdp	367
cdp entry	367
cdp neighbors	368
cdp traffic	368
connection tcp	368
dhcps	368
dhcps lease	369
dhcps pool	369
fr	369
fr lmi	370

fr pvc	370
framer	370
show framer alarms	370
show framer hw	371
ids	371
ids anomaly	371
ids attacks	372
ids flood	372
ids scan	372
ids spoof	372
ius spool	272
ike policy	273
ike policy	273
ike presnared	3/3
1Ke sa	3/3
1ke task	3/4
interface	374
interface ip	374
interface vlan	375
ipsec	375
ipsec ap	375
ipsec policy	376
ipsec proposal	376
lcr	376
lcr accounts	377
lcr connection	377
lcr settings	377
logging	377
logging dest	378
logging file	378
logging internal	378
	270
logging modulos	270
logging modules	270
media connection	279
media connection	3/9
media settings	380
media status	380
media stream	380
mgcp	381
mgcp sc calls	381
mgcp sc endpoints	381
mgcp sc settings	382
mgcp sc status	382
mgcp status settings	382
mgcp server settings	. 382
mgcp server status	383
mgcp ua port	383
mgcp ua status	384
netflow	384
netflow agent	384
netflow filter	384
netflow stats	385
nmon	385
nmon agent	385
nmon trace	385
pritor diace	707
protocol icmp	200
protocol in	200
	30/
ριοτοςοι τςρ	388

protocol udp	390
qos	390
qos group	390
qos link	391
radius client	391
relay	391
relay dhcp settings	392
relay dns	392
relay dns cache	392
relay dns sessions	393
relay dns settings	393
relay sntp	393
relay sntp sessions	393
relay sntp settings	394
relay tftp	394
relay titp cache	394
relay titp sessions	394
relay trip settings	393 392
show rin domon	205
rip routes	205
route	375
route arp	306
route table	396
security	396
security alg	397
security dynamic	397
security nat	398
security policy	398
service	399
service ssh	399
service telnet	399
service web	400
shell terminal	400
sip	400
sip gateway settings	401
sip sc calls	401
sip sc endpoints	401
sip sc settings	402
sip sc status	402
sip server settings	402
sip server status	403
sip server status sip ua port	403 403
sip server status sip ua port sip ua settings	403 403 404
sip server status sip ua port sip ua settings sip ua status	403 403 404 404
sip server status sip ua port sip ua settings sip ua status snmp	403 403 404 404 405 405
sip server status sip ua port sip ua settings sip ua status snmp snmp agent	403 403 404 404 405 405
sip server status sip ua port sip ua settings sip ua status snmp snmp agent snmp community	403 403 404 404 405 405 405 405
sip server status sip ua port sip ua settings sip ua status snmp snmp agent snmp community snmp traps	403 403 404 404 405 405 405 405 406
sip server status sip ua port sip ua settings sip ua status snmp snmp agent snmp community ssl certificate	403 403 404 404 405 405 405 406 406 406
sip server status	403 403 404 404 405 405 405 406 406 406
sip server status	403 403 404 404 405 405 405 405 406 406 406 406
sip server status	403 403 404 404 405 405 405 405 406 406 406 406 407 407
sip server status	403 403 404 404 405 405 405 406 406 406 406 407 407
sip server status	403 403 404 404 405 405 405 406 406 406 406 406 407 407 407
sip server status	403 403 404 404 405 405 405 406 406 406 406 406 407 407 407 407 408 408

switch qos port	. 409
switch qos setting	. 409
switch qos tos	. 409
switch status	. 409
switch vlan	. 409
system	. 410
system dns	. 410
system exceptions	. 410
system hardware	. 411
system info	. 411
system sntp	. 411
system startup	. 412
system watchdog	. 412
user	. 41Z
	. 41Z
user gloups	.413
	.413
voice	.413 /1/
voice iitterhuffer	.414
voice pp	. 414 /1/
	.414
State CLI Commande	.41J
calls quality	415
fr	/16
fr global	<u>416</u>
fr mi	416
fr pyc	. 410 ⊿17
framer	<u>417</u>
ike task	<u>418</u>
interface in	418
insec an	419
media status	420
morn sr	420
mgcp sc calls	. 420
mgcp sc status	. 421
netflow agent	. 422
clear netflow agent	. 422
pmon trace	. 422
protocol	. 423
protocol icmp	. 423
protocol ip	. 424
protocol tcp	. 425
protocol udp	. 426
qos	. 427
qos counters	. 427
stats qos day	. 427
qos group	. 428
qos link	. 428
service web	. 428
sip	. 429
sip sc calls	. 429
sip sc status	. 430
snmp agent	. 431
switch	. 432
switch port	. 432
switch summary	. 433

F		
	Introduction	435
	Expressions	435
	Primitives	435
_		
G	COUNTRY CODES	
	Introduction	. 439
	Configuration Commands	. 439
	Configure Country Code	. 440
	Show Configuration	. 440
н	COMPLIANCE	
	FCC Compliance (US)	. 441
	FCC Telecom Statement	. 441
	Declaration of Conformity	. 442
	Equipment Attachment Regulations (Canada)	. 442
	Canadian Department of Communications Statement	. 443
	Contact Information	. 443
	Supplementary Information	. 443
	Data Standards	. 443
	Switching	. 443
	Routing	. 443
	Security	. 444
	Quality of Service	. 444
	Services	. 444
	Monitoring	. 445
	Voice Standards	. 446
	SIP Session Controller	. 446
	MGCP Session Controller	. 440
	MCCP User Agent	. 447 117
	MOCF User Agent	. 447
I	GOS FUNCTIONALITY	
	Introduction	. 449
	QoS for Converged Networks	. 449
	GoS Technology	450
	GoS in the Network	450
	GoS Features	450
	GoS Processing	. 451
	Advantages of GoS	. 451
	Principles	. 451
	Stages	451
	Stage 1 – Classification	. 452

	2-D QoS Model Matrix	453
	Predictable QoS	454
J	Important Information	

ight Information
-

Κ

ABOUT THIS GUIDE

This chapter provides information about the intended audience for this guide, how this guide is organized, typographical conventions, the use of notices, and related documentation.

Introduction

This document provides guidelines for configuring and monitoring the ICAD80. This guide is designed for network managers, administrators, and technicians who are responsible for the management of networking equipment in Enterprise and Service Provider environments. Knowledge of Telecom technologies and standards including telephony and internet protocols is assumed.

Organization

The following tables describe the content and organization of this guide.

Chapter	Description
1	Starting With ICAD80 provides an overview of ICAD80 capabilities, default settings, and user interface.
2	Using Commands provides information about using CLI commands for online help, saving and showing configurations, and applying configurations in interactive mode.
3	User Management describes users, permissions, and groups, and provides guidelines to create, modify, and remove user access to the network.
4	Interface Configuration provides examples to configure the ICAD80 unit for ethernet access (LAN, WAN, VLAN).
5	System Configuration provides examples for system configuration (SNTP time, DNS client, watchdog).
6	Routing Configuration provides configuration examples for routing (ARP, static routing, dynamic, RIP).
7	Switching Configuration provides configuration examples for switch (port) configuration (LAN, WAN, ARL, port mirroring, VLAN, layer 2 QoS). configurations are related to <i>Chapter 4, Interface Configuration</i> .
8	Security Configuration provides examples for security configuration (Firewall, IDS, NAT, ALG).

Table 1	Document	Organization
---------	----------	--------------

Chapter	Description
9	QoS Configuration provides configuration examples for layer 3 Quality of Service (links, quality service, security).
10	SIP Configuration provides examples to configure SIP devices (server, session controller, user agent).
11	MGCP Configuration provides configuration examples for MGCP devices (server, session controller, user agent).
12	VoIP Survivability provides configuration examples for local call routing.
13	Services Configuration provides configuration examples for services (file system, remote administration, connectivity, authentication).
14	Monitoring provides examples of tracking and monitoring system performance.
Α	Upgrade Software provides examples of upgrading image and configuration software.
С	Third Party Software provides contact information for the third party software referred to in this document.
D	SSH Functionality provides information about SSH as related to user management.
В	Web UI provides examples of using the Web User Interface (monitor, configure, upgrade software).
E	CLI Commands lists the ICAD80 CLI commands for configuration, showing information, and statistics.
F	TCPdump Expressions provides detailed information about using specific tcpdump expressions (options).
G	Country Codes lists the ISO country codes.
Н	Compliance lists the voice and data standards, and FCC compliance.
I	GoS Functionality provides details about Guarantee of Service (GoS).
J	Important Information lists copyright acknowledgements and restrictions.

Table 1 Document Organization (continued)

Typographical Conventions This guide uses the following typographical conventions:

Font	Description
NOTE:	Guidelines provided to use products more effectively.
IMPORTANT:	Important information and/or instructions that must be followed.
CAUTION:	Guidelines provided to avoid equipment damage or faulty application.
WARNING:	Instructions provided to avoid personal injury.
italic emphasi s	This font shows book titles, special terms, or emphasis.
bold emphasis	This font shows strong emphasis.
screen font	This font shows a screen capture: what is displayed on the monitor.
blue screen font	This font emphasizes selected items in a screen capture.

Font	Description
italic screen font	This font is used in command examples as a parameter placeholder – Replace the indicated text with the appropriate real name or value when using the command.
boldface screen font	This font shows commands that you enter or keyboard keys that you press.

Table 2 Text Conventions (continued)

Customer Support

For customer support, please contact your equipment supplier.

1 Starting With ICAD80

This chapter provides introductory information about the ICAD80.

Introduction

This section summarizes ICAD80 capabilities, connecting to the unit, and factory default settings.

IMPORTANT: The software may need to be upgraded. For instructions, see Appendix A, "Upgrade Software".



Figure 1 ICAD80 Connectivity

Overview

The ICAD80 is an integrated device, containing a broad set of networking functionality for voice and data in a single unit: a full featured router with VoIP, QoS and Security capabilities. It slots into the existing network, connected via Ethernet to the WAN access router, to enable the effective provisioning of converged VoIP and data services. It provides session control and service monitoring of VoIP devices on the company's LAN and protects against malicious packet attacks, assures bandwidth for calls and provides operator governed call admission control. The ICAD80 provides sixteen FXS and two FXO ports to provide legacy devices access to the IP network.

Feature Summary

ICAD80 provides the following services.

Session Controller

The ICAD80 has an MGCP and SIP Session Controller and can control up to 500 concurrent calls and 1000 registered devices. It provides VoIP survivability, switching local calls between LAN end points without the need for the proxy - when the WAN is down, calls around the office can still be made. This is coupled with an intelligent lifeline to switch calls to the PSTN via the emergency backup FXO line.

The ICAD80 is fully integrated with the multi-service QoS mechanism (GoS™), for delivery of carrier-class call quality and the firewall to allow reconfiguration and NAT traversal.

User Agent

The ICAD80 provides eighteen telephony interfaces, one FXO can act as a back-up lifeline, and sixteen FXS for connectivity of analog phones or fax machines (if power is down, only one FX0 port is available; otherwise, two FXO ports are available). The User Agent (UA) acts as a VoIP endpoint within a network, performing signalling, media control and allowing the conversion from traditional interfaces to VoIP.

Security

The ICAD80 has a firewall, an advanced Intrusion Detection System (IDS), an Application Layer Gateway (ALG), and support for NAT.

Multi-Service QoS

The ICAD80 has an advanced, yet easy to configure QoS mechanism that ensures the optimal priority and bandwidth allocation for multiple classes of critical traffic. It is compatible with DiffServ with support for TOS bit re-marking.

LAN Switch

The ICAD80 has a 24-port switch, with support for Layer 2 QoS and VLAN.

T1 Interface

A T1 module is available to add to the ICAD80, providing T1 interface, supporting permanent virtual connectivity (PVC).

Monitoring

The ICAD80 dynamically monitors and provides statistics for both voice (statistics, such as MOS scores gathered per call) and data flows.

Management

The ICAD80 can be configured by both a CLI or web interface. The management system allows secure access and changes with SSH and HTTPS.

Connecting to ICAD80

This document assumes installing the ICAD80 and establishing connectivity have been completed. If necessary, refer to the *Business Gateway Installation Guide* that was provided on the CD that was included with the ICAD80.

For configuring the ICAD80 for Telnet access, see "Telnet Server" on page 250.

For information about Web UI, see Appendix B, "Web UI".

Default Settings

This section summarizes the factory default settings of the ICAD80. The following information is derived from the dump command, which was executed prior to configuration.

IP Interface

default setting eth0

config interface ip eth0

- IP address: 0.0.0.0
- No IP mask
- DHCP is on (enabled)

default setting eth1

config interface ip ethl

- IP address/IP mask 192.168.1.1/255.255.255.0
- No DHCP

User Groups

default setting admins

config user groups admins

- access ssh + web + cli + telnet + ftp
- All access rights are available

default setting users

config user groups users

access web + cli

User Accounts

default setting System Access—admin

config user accounts admin

- access ssh + web + cli + telnet + ftp
- group1 admins
- group2 users
- group3 admins
- group4 admins
- group5 admins
- user ID admin

USER MANAGEMENT

This chapter describes the means provided to control access to the ICAD40 unit:

- Adding and removing users
- Setting up groups
- Assigning permission to users and to groups
- Authentication via Radius Client

Introduction

The user management functions control who can log in and whether they can change the ICAD40 configuration or just view information stored in the ICAD40. User access is controlled as follows:

 At login, by the user ID and password entered Access methods for the user ID can be restricted (for example, permission to log in remotely could be denied).

the password must be authenticated (either internally or externally).

• After login, the user's access rights limit what the user can do.

IMPORTANT: The security of the ICAD40 depends on password security. To maintain access security to the ICAD40, passwords should be changed regularly and kept secure.

User Management supports user and group authentication, adding and removing users and groups to the network, and monitoring user activity. User Management can be accessed through CLI commands via console, telnet, and SSH, and through the Web user interface (Web UI).

Following is a summary of User Management functions.

- Enforces access control by requiring login with a valid user ID and password
 - Authenticates the entered password using either strong password hashing (SHA) or external authentication via a Radius client
 - Never stores passwords in clear text
 - Keeps a log of all failed login attempts and logouts
- Limit login attempts
 - A user can attempt to log in from the console port three times. If the user fails all three times, no one can log in to the console port for the next fifteen minutes.
- Log failed login attempts and logouts
- Specified users can be locked out
 - Users can be locked out from interface access methods such as Web and CLI

- An external authentication method, RADIUS, is provided.
- Supports management of users by user groups
 - Multiple users can be logged in simultanously
 - Users can belong to more than one group
 - Each user management element (user accounts, user groups, and associated rights records) can be added, edited, and deleted independently.
 - Can assign rights to read and/or write access by user account and by user group.
 - Enforces who has access to which modules in the system, using specified access methods and under what conditions
- List who is currently connected on the system, from where
- Provides an audit log that records:
 - Account activities
 - Password changes
 - . Login events

User Accounts, Groups and Rights

User access to the ICAD40 is managed using user accounts, user groups, and user rights settings. The initial factory settings for an ICAD40 already define the following:

- Two user groups: one for administrators (admins) and one for other users (users). The admins user group is granted all access modes and; the other user group is granted only web and CLI access.
- Two user accounts: one for administrators (admin) and one for other users (user). The admin user is granted all access modes and all access rights; the other user account is granted only web and CLI access and its access rights are restricted. The admin account belongs to both predefined user groups (admins and users); the other user account belongs only to the users user group.
- Three rights settings: one for the admins user group and the other two for the users user group. All rights are granted to admin; the two rights settings for the users group grant read-only access to some objects and read and write access to other objects.
- *NOTE:* The predefined user management configuration cannot be deleted or renamed. You cannot delete or rename the two user groups (admins and users), the two user accounts (admin and user), or the three user rights settings (admin, useradv, and userbasic).

Configuration Main Menu

NPE> config user

Table 3 describes the parameters for config use.

NOTE: Table 3 shows the main menu of user. *See the following sections for details.*

Table 3 User Accounts Configuration Main Menu

Parameter	Description		
user accounts	User accounts for system access		
user groups	Users groups management and configuration		
user rights	Rights for R/W access to elements		

Adding a User Account

Before you add a new user account or change an existing user account, you should display the current user accounts and user groups by entering the commands: show user accounts and show user groups.

Configuration Requirements

There are no configuration requirements for adding a user account.

Configuration Commands

NPE> config user account

Table 4 describes the parameters for config user account.

Parameter	Description
[name]	User name
access	Access mode for this user (all + ssh + web + cli + telnet + ftp + none)
auth	Whether internal or external authorization is required (SHA RADIUS)
groupl	The first group the user belongs to (admins users -none-)
group2	The second group the user belongs to (admins users -none-)
group3	The third group the user belongs to (admins users -none-)
group4	The fourth group the user belongs to (admins users -none-)
group5	The fifth group the user belongs to (admins users -none-)
password	The password assigned to the user
inherit	Whether or not user inherits rights from groups
enabled	Whether or not user is enabled

Table 4 User Account Configuration Parameters

Add User Account

This example assumes that the user should be given read and write access to the ICAD40, but only while connected directly to the console port: no remote access allowed.

name of user account: user1
access methods allowed: cli
group membership: admins
assigned password: test123

NOTE: This example is shown in interactive mode. For more information, see "Interactive Mode" on page 55.

1 Enter the following commands:

```
*NPE*> config user account user1 <enter>
   Entering interactive mode: ctrl^z | 'exit', ctrl^c | 'quit'
   TAB to cycle parameter options
*user-accounts-user#*> access cli group1 admin password test123
*user-accounts-user#*> exit
```

2 To save the configuration, enter:

NPE> save

Show User Account

- To show the settings for account user1, enter the following command:
 NPE*> show user account user1
- The display will be similar to the following:

Users:							
Name	Access		Auth Group1 Group3	Group5	Passw	vord In	nherit
			Group2 Group4			Enab]	led
userl	cli	SHA	users	****	***	yes	
							ves

NOTE: Password *is encrypted; it is shown as asterisk characters.*

Adding Group

This section provides examples for adding groups.

Configuration Requirements

There are no configuration requirements for adding a group.

Configuration Commands

NPE> config user groups

Table 5 describes the parameters for config user groups.

Table 5	User Groups	Configuration	Parameters
14010 0	000.0.00000	e en inganadion	

Parameter	Description
[name]	Group name
access	Access mode for this group (ssh web cli telnet ftp all none)
auth	Whether internal or external authorization is required (SHA RADIUS)
all	Whether or not access and auth should be allowed if not specified

Add Group

This example adds a new group as follows.

```
name: dev
access: all (ssh, web, cli, telnet, ftp)
unspecified access and authorizations: yes (allowed)
```

- 1 To add a group, enter the following command: NPE> config user group dev access all all yes
- 2 To save the configuration, enter: *NPE*> save

Show Group

- To show the settings for group dev, enter the following command:
 NPE> show user group dev
- The display will be similar to the following:

Groups:			
Name	Access	Authorization	Allow All
dev	ssh + web + cli + telnet + ftp	SHA	yes

Configuring User Rights

This section describes how to configure a record that defines the access a group has to certain objects. The available access rights are read, write, and execute. Read allows the viewing of data; write allows the writing of data; execute is not currently used.

A group can have more than one rights record defined for it. For example, the default rights records useradv and userbasic are both defined for the same user group: the user group users. In this case, two rights records are defined so that the user group is granted different access to different objects in the system.

The useradv record applies to objects that belong to Admins; it grants only read access.

The userbasic record applies to objects that belong to Users; it grants both read and write access.

Command Authority

Commands are objects that belong to either Admins or Users. When you list the online help for a command (by entering the command followed by a ? or tab key), you see a line for Authority (see page 51). If the Authority is Admins, the command is an object that belongs to Admins and the right to use that command is governed by the rights record that grants access to objects belonging to Admins.

In general, commands that require write access, such as config commands, have authority Admins. Commands that only display data, such as show and stats, have authority Users. Similarly, maintenance commands that require write access have authority Admins.

The notable exception is the save command that saves configuration changes; it has authority Users so it is available to all users belonging to groups admins or users.

Configuration Requirements

Setting user rights can only be applied to defined groups: those already added to the system. For more information, see "Adding Group" on page 66.

NOTE: In most cases, the default settings provide the appropriate permissions per user level. It is recommended to not change the settings unless deemed necessary, and the effects of authority and ownership are understood.

Configuration Commands

NPE> config user rights

Table 6 describes the parameters for configuring user permission.

Parameter	Description
[id]	Text identifier
access	Access mode for this rights record (read, write, execute) (read write execute all none)
gname	Group name for this rights record (admins users)
object	Object name for this rights record (Admins Users)

Table 6 User Rights Parameters

Configure User Rights

This example sets user rights as follows.

```
id: user (user being configured)
access modes allowed: read
group name: users
object name: Users
```

1 Enter the following command:

NPE> config user rights user access read gname users object Users

2 To save the configuration, enter:

NPE> save

Show User Rights

- To show the current configuration of user rights enter the following command: NPE> show user rights
- The display will be similar to the following:

```
Access Rights:
Identifier Access mode Group name Object name
------user read users Users
```

Deleting a User Account

This section describes how to delete a user account.

Configuration Requirements

An user account must exist.

NOTE: The user accounts admin and user cannot be removed or renamed.

Configuration Commands

NPE> del user accounts

Table 7 describes the parameters for del user accounts.

Table 7 Delete User Account Parameter

Parameter	Description	
[name]	User name	

name

Name of the user account to be deleted.

Delete User Account Example

- To remove an user account, enter the following command: NPE> del user account user1
- To save the configuration, enter:
 NPE> save

Deleting a User Group

This section describes how to delete a user group.

Configuration Requirements

NOTE: The default groups named users and admins cannot be deleted or renamed.

Configuration Commands

NPE> del user groups

Table 8 describes the parameters for del user groups.

Table 8 Delete Group Parameters

Parameter	Description
[name]	Group name

name

Name of the user group to be deleted.

Delete Group Account Example

- To delete a user group named dev,, enter the following command:
 NPE> del user groups dev
- To save the configuration, enter:
 NPE> save

Deleting User Rights

This section describes how to delete a user rights record.

Configuration Requirements

NOTE: The default right records named admin, useradv, and userbasic cannot be renamed or deleted.

Configuration Commands

NPE> del user rights

Table 9 describes the parameter for del user rights.

Table 9 Delete Rights Parameters

Parameter	Description
[name]	Right name

name

Represents the name of an existing user rights record.

Delete User Rights Example

- To remove a user rights record named user, enter the following command: NPE> del user rights user
- To save the configuration, enter:
 NPE> save

Password Entry

All access to the ICAD80 requires entry of a valid user ID and password. The ICAD40 factory settings define two user IDs: admin with password admin; user with password netcat. The ICAD80 installation procedure recommends that these passwords be changed immediately.

NOTE: For security reasons, it is recommended that all passwords be changed on a regular basis.

Failed Login Attempts

A user can attempt to log in from the console port three times. If the user fails all three times, the console is locked out and no one can log in to the console port for the next fifteen minutes.

When attempting to log in remotely via Telnet or SSH, the user is given three login attempts and then the session is ended.

All invalid login attempts are recorded in the audit log. For more information about the audit log, see "Audit Logging" on page 273.

Change Password Example

The administrator, the user logged in with user ID admin, can change the password for any user account. This is done using the config user account command described on page 65. When logged on, all users can change their own passwords.

1 Enter the command password.

NPE> password

2 Enter the old password.

Old Password: *****

3 Enter the new password.

New Password: ********

4 Re-enter the new password.

Verify Password: *********

5 To save the configuration, enter:

NPE> save

Showing Active Users

To see which users are currently connected to the ICAD80, use the maintenance command whoison; its display shows the source IP address of the user and type of access in effect. An example follows.

- Enter the following command:
 - NPE> whoison
- The display will be similar to the following:
| User | Source IP | Туре | |
|-------|-----------|----------|--|
| admin | Unknown | Terminal | |
| user | 10.0.1.2 | Web | |

Type

Indicates how the user is connected to the ICAD80: Terminal, SSH, Telent, or Web.

RADIUS Client

Radius client provides an authentication service.

Users can be authenticated when logging in the system using the RADIUS protocol.

- Multiple Radius authentication records created by the Web UI and the CLI (maximum of 20)
- Legacy authentication, enabling ICAD80 to function as Network Access Server (NAS)
- User management authentication provides Radius authentication and Secure Hash Algorithm (SHA).
- Radius authentication records and users are mapped: keyed on the Primary Key user name
- Compatibility with standard Radius servers

Configuration Requirements

A user account must be created with authentication set to "RADIUS". For more information about user management, refer to "User Management" on page 63.

Configuration Commands

NPE> config radius client

Table 10 describes the parameters for config radius client.

Table 10 Radius Client Configuration Parameters

Parameter	Description
[user]	User name for the client (admin user)
enabled	Enable/Disable radius client
auto	Automatically bind to specified interface
authserver	Authorization server for the client
secret	Shared secret for the client
bindaddr	Binding IP address for the client
interface	If auto, the interface that Radius will run over (eth0 eth1 -none-)

Configure RADIUS Authentication

This example configures a user with authentication set to Radius.

- 2 Enter the following commands:

```
user-accounts-user#> access web + ssh + cli
user-accounts-user#> auth radius
user-accounts-user#> group1 users
user-accounts-user#> password test123
user-accounts-user#> exit
```

3 To save the configuration, enter:

NPE> save

Show Configuration

- To show the current Radius Client configuration, enter: NPE> show user account user16
- The display will be similar to the following:

Radius Client:

User	Enable	d Automat:	ic Auth	Secret	Bind
Interface					
user16	yes	yes	radius-usa	testing123	0.0.0.0

Configure Radius Client

This example configures Radius Client as follows:

User account name: RadiusUser Radius server: radius.wan.com Shared secret: secret Interface: eth0

1 Enter the following command:

NPE> conf radius client RadiusUser CLI enters interactive mode. Entering interactive mode: ctrl^z | 'exit', ctrl^c | 'quit' TAB to cycle parameter options

2 Enter the following commands:

radius-cl-user#> enabled yes
radius-cl-user#> authserver radius.wan.com
radius-cl-user#> secret secret
radius-cl-user#> interface eth0
radius-cl-user#> exit

3 To save the configuration, enter:

NPE> save

Show Configuration

- To show the current Radius configuration, enter: NPE> show user account RadiusUser
- The display will be similar to the following: Radius Client:

User	Enabled	Automatic	Auth	Secret	Bind	Interface
RadiusUser	yes	no	radius.wan.com	secret	0.0.0.0	eth0

Show logs

Radius activity is reported in the system logging.

- To show the Radius logs, enter the following command:
 NPE> show logging internal
- The display will be similar to the following:
 - (E)02:36:31: rc_send_server: bind: radius.wan.com: errno = 0x31
 - (C)02:36:31: RADIUS Authentication failure
 - (E)02:36:31: Cannot authenticate Radius!
 - (C)02:36:31: Cannot initialize Radius user: RadiusUser
 - (E)02:36:31: Cannot authenticate RADIUS user RadiusUser
 - (W)02:36:31: RadiusUser INVALID LOGON at TUE MAR 06 02:34:45 2007

INTERFACE CONFIGURATION

This chapter provides information and configuration examples for the interfaces for routing traffic:

- LAN
- WAN
- T1/Frame Relay
- VLAN

Introduction

A single Ethernet interface, eth1, represents the LAN ports. The Ethernet interface eth0 represents the WAN port. VLAN interfaces, Vif, can be added to either LAN or WAN ports.

ICAD80 routes traffic between the following interfaces:

LAN

eth1 provides LAN ports to connect to the Corporate Network.

WAN (ethernet)

eth0 can be used as a WAN port to connect to the external Internet.

T1/Frame Relay

Frame Relay is a link layer that can be run over T1, and can provide the logical connection of a permanent virtual circuit (PVC), and support security and guaranteed bandwidth. T1 provides 1.544 Mbps bandwidth on a WAN port.

NOTE: T1/Frame relay is only available when the T1 module is installed in the ICAD80. When installed, the ethernet (10/100) port is not available for use as a WAN port; however, the ethernet port can be used as a management port.

VLAN

A virtual LAN (VLAN) is a logically independent network, a logical subcomponent of a physical network. Each VLAN functions as a separate network, which isolates internet multicasts and broadcasts to and from other groups.

The ICAD80 supports IEEE 801.Q VLAN: up to 512 VLANs on the switch and up to 16 VLAN interfaces (Vif) in the IP stack. VLANs are integrated into the host IP stack as separate layer 2 ethernet interfaces.

By default, VLAN is not configured; traffic is routed between eth1 and eth0. VLAN can be configured through eth0 or eth1, but not the frame relay (fr0, fr1, etc).

ICAD80 provides 24 physical LAN ports and one physical WAN port. For information about port configuration, see Chapter 7, "Switching Configuration".

Configuring LAN Interface (eth1)

This section provides configuration examples for the LAN interface.

Configuration Requirements

The eth1 ports should be configured. See "Configuring LAN Ports" on page 105.

Configuration Commands

NPE> config interface ip eth1

Table 11 describes the configuration parameters for config interface ip eth1.

Parameter	Description
[if]	Interface to change behavior of (eth0 eth1 vif0 vif1 ppp0 ppp1 ppp2 ppp3)
ip	IP address and mask of interface
mtu	The Maximum Transmission Unit (MTU) of the interface
dhcp	Whether or not DHCP is enabled for the interface
status	Configuration status of the interface (up down)
speed	Speed/Duplex of eth0 (Auto 10Half 10Full 100Half 100Full)

NOTE: Speed only applies to the WAN interface (eth0); it does not apply to the LAN interface (eth1).

Configure eth1 Interface

The following example sets the eth1 interface as follows:

IP address: 192.168.1.1 IP mask: 255.255.255.0

- 1 Enter the following command: NPE> config interface ip eth1 ip 192.168.1.1/24
- 2 To save the configuration, enter:

NPE> save

Show Configuration

- To show the current configuration, enter the following command: NPE> show interface ip eth1
- The display will be similar to the following:

"ethl" info: Interface eth1 Flags (A843) < UP BROADCAST RUNNING SIMPLEX LINKUP</pre> MULTICAST > IP Address/Mask 192.168.1.1/255.255.255.0 MTU 1500 DHCP off MAC Address 00:15:93:FE:00:CD Speed N/A

Configuring WAN Interface (eth0)

This section provides configuration examples for the WAN interface.

Configuration Requirements

The eth0 port should be configured. See "Configuring WAN Port" on page 109.

Configuration Commands

NPE> config interface ip eth0

Table 12 describes the parameters for config interface ip eth0.

Table 12	WAN Interface Parameters

Parameter	Description
[if]	Interface to change behavior of (eth0 eth1 vif0 vif1 ppp0 ppp1 ppp2 ppp3)
ip	IP address and mask of interface
mtu	The Maximum Transmission Unit (MTU) of the interface
dhcp	Whether or not DHCP is enabled for the interface
status	Configuration status of the interface (up down)
Speed	Speed/Duplex of eth0 (Auto 10Half 10Full 100Half 100Full)

NOTE: Speed applies only to the eth0 port; it does not apply to the T1 interface.

Configure eth0 Interface

The port will be configured as follows:

- DHCP: enabled
- 1 Enter the following command:
 - NPE> config interface ip eth0 dhcp on
- 2 To save the configuration, enter:

NPE> save

Show Configuration

- To show the current configuration of interface eth0, enter the following: NPE> show interface ip eth0
- The display will be similar to the following:

"eth0" info:

Interface	eth0
Flags MULTICAST >	(A843) < UP BROADCAST RUNNING SIMPLEX LINKUP
ID Address/Mask	66 206 164 212/255 255 255 224
MTU	1500
DHCP	on
MAC Address	00:E0:45:10:00:90
Speed	FULL100(AUTONEG)

Configuring T1 Line

This section provides information and configuration examples about the T1 WAN line. This feature is available when the optional T1 module is installed in the ICAD80.

Configuration Requirements

The T1 module is installed in the ICAD80.

Configuration Commands

NPE> config framer hw

Table 13 describes the parameters for config framer hw.

Parameter	Description
type	Line type (T1)
mode	Layer 2 protocol (FR)
framing	Framing protocol (ESF, D4)
code	Line coding: B8ZS, HDB3, AMI
clock	Clock mode
loop	Loopback type
lbo	T1: Short Haul (ft): 0-655, Long Haul: -1 (0dB), -2 (-7.5dB), -3 (-15dB), -4 (-22.5dB)
mask	Timeslot mask for fractional connection (e.g. 1,2,3,4-32)

Table 13 Frame Relay Configuration Parameters

Additional information follows.

type

At the release of this document, only T1 is supported; E1 is not available.

mode

In this release, only Frame Relay is supported

- framing
 T1 is typically setup for ESF (extend super frame).
- code
 T1 is typically setup for B8ZS (bipolar with 8-zero substitution). This setup allows 64 kbps per channel.
- clock

8 kHz network clock master: ICAD80 provides the network system clock slave: ICAD80 follows the network system clock The default value is slave.

mask

T1 mode can provide 24 slots for fractional services: set to enable timeslots in a fractional connection. 24 timeslots are available in a T1 line which can be specified individually (separated by commas, such as 1, 2, 3, etc.) or as ranges (hyphenated, such as 1-24).

lbo

Modifies the line build out of the interface: compensates for signal attenuation from the source (such as a repeater) direct to the ICAD80.

A positive value denotes short haul LBO; the units are in feet. A negative value specifies a long haul LBO; the units are in decibels.

For most configurations, this parameter should be used at its default value: -2 (-7.5 dB) When used as a smart jack, lbo should be set to 0.

loop

Enables loopbacks in the framer: remote Tx to remote Rx, or local Tx to local Rx. Used for debug. Default value is off.

This parameter should only be used for debug. When debug is complete, disable loop.

Configuring T1 Line

This example configures the T1 line as follows:

Type: T1 (default value) Mode: Frame relay (default value) Framing type: ESF code: B8ZS clock: slave (ICAD80 retrieves clocking information from the T1 line)

1 Enter the following command:

NPE> config framer hw type t1 mode fr framing esf code b8zs clock slave

2 To save the command, enter:

NPE> save

Show Configuration

- To show the current configuration, enter the following command: NPE> show framer hw
- The display will be similar to the following:

Framer Settings:

Туре	Mode	Framing	Code	Clock	Loop	LBO	Mask
 T1	FR	ESF	B8ZS	SLAVE	OFF	-2	1-24

Configuration Status

Assuming the data communications equipment (DCE) at the other end is configured correctly, the line should be functional. The frame relay configuration can be verified as follows:

LEDs

Check the LEDs on the T1 WAN module (see Figure 2). They should both be off; on indicates failure, as described below.

- Red LED indicates loss of carrier
- Amber LED indicates loss of synchronization
- Loopback, Slave Mode

When the ICAD80 is configured as a slave, inserting a loopback plug in the WAN interface should cause the red (carrier) LED to turn off; the amber LED should remain on.

Loopback, Master Mode

When the ICAD80 is configured as a master, inserting a loopback plug into the interface should cause both LEDs to turn off.

If the NP80 is connected to a DCE and the amber LED flashes rapidly, check the configuration. This may indicated two masters are connected to the same link.

If any of the above problems occur and cannot be resolved, contact Customer Support.

To view the frame relay status remotely, see "Show T1 Alarms" on page 80.



Figure 2 ICAD80 WAN Module

Show T1 Alarms

The T1 alarm status can be viewed with the command show framer alarms. For viewing the alarm status on the LEDs of the T1 module, see "Configuration Status" on page 79.

To show the T1 alarm status, enter the following command:

NPE> show framer alarms

The display will be similar to the following:

Framer Alarms:

Loss of carrier	inactive
Loss of synchronization	inactive
Alarm Indication Signal	inactive
Remote alarm indication	inactive
Loss of carrier count	0
Loss of synchronization count	0
Alarm Indication Signal count	0
Remote Alarm Indication count	0

NOTE: It may take several seconds after the fault condition is corrected before the alarm turns off (returns to inactive).

Configuring PVC (Frame Relay)

This section provides information and an example of configuring Permanent Virtual Circuits (PVC).

Configuration Requirements

There are no configuration requirements.

Constraints

Traffic is not sent unless the T1 line is up.

UP to 5 PVCs can be supported.

Up to five DLCIs (IP) can be configured per PVC.

PVC can be setup without T1; however, if setup with T1 and T1 goes down, data sent over the PVC line will be discarded.

Configuration Commands

NPE> config fr pvc

Table 14 describes the parameters for config framer pvc.

Table 14 Frame Relay PVC Configuration Parameters

Parameter	Description
[dlci]	The data link connection identifier
interface	IP interface that this PVC is bound to

[dlci]

DLCI identification number: determines who (which other PVC in the network) the ICAD80 can talk to. The range of numbers is 16-1022. The assigned number must match the identification number of the DLCI at the remote. The default value is 16.

interface

This parameter is non-configurable; it displays which IP interface the system has allocated to the PVC.

Configure PVC

The following example creates a new PVC as follows:

DLCI: 100

1 Enter the following command.

NPE> config fr pvc new dlci 100

2 To save the command, enter:

NPE> save

Policing Traffic

The following example sets the bandwidth to 1.544 Mbps. Is is assumed only one PVC exists and that fr0 was assigned as the IP interface. For more

1 Enter the following command.

NPE> config qos link fr0 max 154400

2 To save the command, enter:

NPE> save

For more information about QoS, see "QoS Configuration" on page 157 and "GoS Functionality" on page 449

Show PVC

- To show the current PCV configuration, enter the following command.
 NPE> show fr pvc
- The display will be similar to the following: Frame Relay PVCs:

DLCI	Committed burst	IP Interface
CIR	Excess burst	LMI Status

100	0	fr0
0	0	Down - invalid

- IP interface fr0 is bound to the PVC.
- The PVC is down, according to LMI.
 Packets sent to or received from a PVC that is down are marked as invalid and discarded in the Frame Relay AP.

PVC Statistics

This section provides information and examples of PVC and global frame relay statistics.

NPE> stats fr

Table 15 describes the parameters for stats fr.

Table 15	FR Statistics
----------	---------------

Parameter	Description
pvc <dlci></dlci>	PVC statistics
global	Global frame relay statistics

PVC

NPE> stats framer pvc <dlci>

If DLCI is not provided, stats for all currently configured PVCs will be displayed. An example follows.

- Enter the following command:
 NPE> stats fr pvc
- The display will be similar to the following:

DLCI	RxPackets	RxBytes	TxPackets	TxBytes
100	0	0	0	0

Global Frame Relay

NPE> stats fr global

- To view the global frame relay statistics, enter the following command: NPE> stats framer global
- The display will be similar to the following: Global frame relay statistics:

Received packets	429
Received bytes	8929 bytes
Transmitted packets	8
Transmitted bytes	704 bytes
Valid packets received	0
Invalid packets received	30
Valid packets transmitted	0
Invalid transmit packets	8

CRC Errors	8
Aborts	1
Overruns	0
In progress errors	0
Input queue full count	0

Clear Statistics

To clear the statistics for PVC and Global Frame Relay, enter the following command:

NPE> clear fr pvc | global

Configuring Local Management Interface

The Local Management Interface (LMI) provides a series of network management features for Frame Relay. The NP80 supports three types of LMI: ANSI Annex D, ITU Q933A and Cisco Gang of Four.

LMI is only supported in DTE mode. The ICAD80 initiates requests; it does not respond.

Configuration Requirements

The T1 must be up and running. See "Configuring T1 Line" on page 78.

The framer must be configured. See "Configuring PVC (Frame Relay)" on page 80.

Configuration Commands

NPE> config fr lmi

Table 16 describes the parameters of config fr lmi.

Table 16 Frame Relay LMI Parameters

Parameter	Description
type	LMI Type (none autodetect ansi q933A gfour)
t391	The Link Integrity Verification Timer $(5-30)$
n391	Threshold to send full status enquiry messages $(1-255)$
n392	Number of errors in window before link is declared down $(1-10)$
n393	Monitored events count(1–10)

type

Specifies which LMI to use. none turns off LMI; only use this when LMI is not needed. The default setting is autodetect: which type of LMI.

none turns off LMI

NOTE: If the LMI type is set to autodetect the LMI type, the result of the auto detection is shown with the command show framer lmi. See "Show LMI" on page 84.

∎ t391

The Link Integrity Verification Timer is the duration between link integrity messages. t391 is typically set to 10 seconds (default value). The timer units are seconds.

∎ n391

Specifies the number of t391 messages (partial enquiries) that should be sent before sending a full status enquiry.

Example: if n391 is set to 6 (default value), after 5 partial enquiries, the next (6th) will be a full enquiry.

n392

Specifies the required number of error events in the event window to declare the link down. Default value: 4.

LMI uses this value with n393 to determine if the PVCs should be declared as down: the number of errors exceeds the allotted number within the event window (n393). Should thresholds exceed in both n392 and n393, all PVCs will be marked as down.

∎ n393

Specifies the size of the LMI event window: an internal buffer. Default value: 3. LMI uses this value with n392 to determine if the PVCs should be declared as down: the number of

errors exceeds the allotted number (n392) within the event window. Should thresholds exceed in both n392 and n393, all PVCs will be marked as down.

Configure LMI

This example configures the LMI as follows:

type: LMI autodetect

1 Enter the following command:

NPE> config fr lmi type auto

2 To save the configuration, enter:

NPE> save

Show LMI

- To show the current LMI configuration, enter the following command: NPE> show fr lmi
- The display will be similar to the following:

LMI Status:

Type Discovered	autodetect gfour
Т391	10 seconds
N391	б
N392	3
N393	4

Statistics

- To view the frame relay LMI statistics, enter the following command: NPE> stats fr lmi
- The display will be similar to the following:

LMI Statistics:		
Host interrupts	363	
Received packets	363	
Received bytes	4425	bytes
Transmitted packets	372	
Transmitted bytes	4425	bytes

Local sequence number	109
Remote sequence number	108
Retransmits	0
Packets rejected by LMI stack	0

Clear Statistics

To clear the statistics, enter the following command: NPE> clear fr lmi

NOTE: The local sequence number, remote sequence number and number of retransmits are private to the LMI stack; they cannot be cleared with this command.

Configure PVC Interface

This section provides information and an example of configuring the PVC interface.

When a PVC interface is configured, the system binds in IP interface to it. The IP interface can be accessed by other aspects of the system, such as firewall, GoS configuration, etc.

Assigned IP Interface

To determine which IP interface the system has assigned to a particular PVC, enter the following command:

NPE> show fr pvc

The display will be similar to the following:

Frame Relay PVCs:

DLCI

16

IP Interface LMI Status _____

> fr0 Up - valid

- The example above indicates **PCV** 100 is bound to **fr0** (the PVC interface).
- The range of values of the PVC interface is fr0 fr4

Configuring PVC Interface

The PVC interface is configured with the command config interface ip.

This example configures the PVC interface as follows:

Assigned IP address to fr0: 1.2.3.7/8

1 Enter the following command:

NPE> config interface ip fr0 ip 1.2.3.7/8

To save the command, enter: 2

NPE> save

Show PVC Interface

- To show the PVC interface, enter the following command: NPE> show interface ip
- The display will be similar to the following:

"eth0" info:

```
Interface
                      eth0
                        (A843) < UP BROADCAST RUNNING SIMPLEX LINKUP
   Flags
MULTICAST >
  IP Address/Mask
                     192.168.134.214/255.255.255.0
  MTU
                     1500
  DHCP
                     off
  MAC Address
                     00:12:52:73:ED:B3
  Speed
                     AUTONEG
"ethl" info:
  Interface
                      eth1
   Flags
                        (A843) < UP BROADCAST RUNNING SIMPLEX LINKUP
MULTICAST >
  IP Address/Mask
                      10.0.1.1/255.255.255.0
  MTU
                     1500
  DHCP
                     off
  MAC Address
                     00:12:52:73:ED:B4
  Speed
                     N/A
"fr0" info:
   Interface
                        fr0
   Flags
                        (20C1) < UP RUNNING NOARP LINKUP >
   IP Address/Mask
                       1.2.3.7/255.0.0.0
   MTU
                        4096
   DHCP
                       off
                       00:00:00:00:00:00
   MAC Address
   Speed
                       N/A
```

Configuring VLAN

The following sections provide information and examples for configuring VLAN Interface. For information about VLAN switch configuration, see "Configuring VLAN" on page 118.

Configuring VLAN Interface

This section provides information and examples for configuring VLAN interfaces.

VLAN enables logically independent networks within a physical network, which can be used to isolate specified groups from other groups: isolate multicasts, protect data, etc.

By default, VLAN is not configured; traffic is routed between eth1 and eth0.

VLAN can be configured through eth0 or eth1, but not the frame relay (fr0, fr1, etc).

An IP address is assigned to a VLAN interface, which enables the ICAD80 to route traffic between this VLAN and other networks.

NOTE: When an IP address is assigned to a VLAN interface, the Firewall, by default, is closed for this interface. Rules need to be added to use the IP address. See "Configuring Firewall (Security Policies)" on page 128.

Configuration Requirements

VLAN must exist on the switch. See "Configuring VLAN" on page 118.

The maximum number of VLAN interfaces is 16.

Configuration Commands

This section describes the CLI commands for configuring VLAN interface.

VLAN Interface Configuration

NPE> config interface vlan

Table 17 describes the parameters for config interface VLAN.

Table 17 VLAN Interface Parameters (VLAN)

Parameter	Description
[vid]	VLAN ID for VLAN
	Range: 1 — 4095.
interface	Local interface to use for VLAN
	eth1 for VLAN configured on LAN. eth0 for VLAN configured on WAN.
status	VLAN on/off
comment	VLAN Comment (if any)
	Maximum length 256 characters. Special CLI characters are not allowed.

VLAN IP Address Assignment

NPE> config interface ip

Table 18 describes the parameters for config interface ip.

Table 18 VLAN Interface Parameters (IP)

Parameter	Description
[if]	Interface to change behavior of (eth0 eth1 vif0)
ip	IP address and mask of interface
mtu	The Maximum Transmission Unit (MTU) of the interface
vid	VLAN ID for interface
dhcp	Whether or not DHCP is enabled for the interface
status	Configuration status of the interface (up \mid down)
speed	Speed/Duplex of eth0 (Auto 10Half 10Full 100Half 100Full)

NOTE: Speed applies only to the eth0 port; it does not apply to VLAN interfaces.

Configure VLAN Interface

This section provides two examples of configuring VLAN interface.

Example 1

The following example shows VLAN 1 configured with LAN port 4.

- Enter the following command:
 NPE> show switch vlan
- The display will be similar to the following:

Switch	n VLAN:										
VID	VLAN Name	WAN	Ρ1	P2	РЗ	P4	•	•	•	P24	
1	MyLANVLAN	*	*	*	*	U					
2	MyWANVLAN	Т	*	*	*	*					

The following example assigns an IP address to the VLAN interface:

```
VLAN ID: 1
IP address: 192.168.135.1
IP mask: 255.255.255.0
```

1 Create the VLAN interface for VLAN 1. Enter the following command: NPE> config interface vlan 1 interface eth1

NOTE: The system automatically create the virtual interface, vif0.

- 2 Assign an IP address to the VLAN interface. Enter the following command: *NPE*> config interface ip vif0 ip 192.168.135.1/24
- 3 To save the configuration, enter:

NPE> save

Example 2

The following example shows VLAN 2 configured with WAN port.

- Enter the following command:
 NPE> show switch vlan
- The display will be similar to the following:

Switch VLAN:

VLAN Name		WAI	N	Ρ1	P2	P3	P4	•	•	•	P24		
MyWANVLAN		т		*	*	*	*						
MYWANVLAN	Т	,	*	*	*	*							
	VLAN Name MyWANVLAN MyWANVLAN	VLAN Name MyWANVLAN MyWANVLAN T	VLAN Name WAI MyWANVLAN T MyWANVLAN T	VLAN Name WAN MyWANVLAN T MyWANVLAN T *	VLAN Name WAN P1 MyWANVLAN T * MyWANVLAN T *	VLAN Name WAN P1 P2 MyWANVLAN T * * MyWANVLAN T * *	VLAN Name WAN P1 P2 P3 MyWANVLAN T * * * MyWANVLAN T * * *	VLAN Name WAN P1 P2 P3 P4 MyWANVLAN T * * * * MyWANVLAN T * * * *	VLAN Name WAN P1 P2 P3 P4 . MyWANVLAN T * * * * MyWANVLAN T * * * * T * * * *	VLAN Name WAN P1 P2 P3 P4 MyWANVLAN T * * * * MyWANVLAN T * * * * T * * * *	VLAN Name WAN P1 P2 P3 P4 MyWANVLAN T * * * * MyWANVLAN T * * * *	VLAN Name WAN P1 P2 P3 P4 P24 MyWANVLAN T * * * * MyWANVLAN T * * * *	VLAN Name WAN P1 P2 P3 P4 P24 MyWANVLAN T * * * * MyWANVLAN T * * * *

The following example assigns an IP address to the VLAN interface:

VLAN ID: 2 IP address: 192.168.136.1 IP mask: 255.255.255.0

1 Create the VLAN interface for VLAN 1. Enter the following command: NPE> config interface vlan 2 interface eth0 NOTE: The system automatically create the virtual interface, vif1

2 Assign an IP address to the VLAN interface:

```
*NPE*> config interface ip vif1 ip 192.168.136.1/24
```

3 To save the configuration, enter: *NPE*> save

Show VLAN Interface

- To view the VLAN interface configuration, enter the following commands: NPE> show interface vlan
- The display will be similar to the following:

Interfaces:

VID	Interface	Status	VIF	Comment
1	eth1	on	vif0	
2	eth0	on	vif1	

- To view the IP address assigned to VLAN interface, enter the following command: NPE> show interface ip
- The display will be similar to the following:

"vif0" info:

Interface	vifO
Flags	(A843) < UP BROADCAST RUNNING SIMPLEX LINKUP
MULTICAST >	
IP Address/Mask	192.168.135.1/255.255.255.0
MTU	1500
DHCP	off
MAC Address	00:19:09:74:00:01
Speed	N/A
"vif1" info:	
Interface	vifl
Flags	(A843) < UP BROADCAST RUNNING SIMPLEX LINKUP
MULTICAST >	
IP Address/Mask	192.168.136.1/255.255.255.0
MTU	1500
DHCP	off
MAC Address	00:19:09:74:00:00
Speed	N/A

Modify VLAN Interface

After a VLAN is created, it can only be turned on or off.

Also, the VLAN interface can be configured as a normal interface, as described below.

This example modifies VLAN as follows: VLAN 1: activate

IP address: modify and modify its IP address.

- 1 Enter the following command to activate VLAN 1. NPE> config interface vlan 1 status on
- 2 Enter the following command to modify the IP address of vif0. NPE> config interface ip vif0 ip 1.2.3.4/24
- 3 To save the configuration, enter: *NPE*> save

Remove VLAN Interface

To remove a VLAN, both the IP address assigned to the VLAN interface and the VLAN interface need to be removed.

When a VLAN is removed, the devices attached to that VLAN will no longer be able to communicate with the ICAD80.

The following examples remove VLANs:

VLAN 1

IP interface: delete vif0

VLAN interface: delete VLAN 1

VLAN 2

IP interface: delete vif1 VLAN interface: delete VLAN 2

1 To remove the VLAN 1, enter the following:

NPE> del interface ip vif0 NPE> del interface vlan 1

- 2 To remove VLAN 2, enter the following: NPE> del interface ip vif1 NPE> del interface vlan 2
- 3 To save the configuration, enter:

NPE> save

9 QOS CONFIGURATION

This chapter provides guidelines and examples for configuring Quality of Service, which is based on Guarantee of ServiceTM.

Introduction

The ICAD80 incorporates a sophisticated Quality of Service architecture known as Guarantee of Service[™] (GoS). This chapter provides examples of configuring Guarantee of Service[™] (GoS). For details of how GoS operates, see "GoS" on page 157 and Appendix I, "GoS Functionality".

The ICAD80 uses our patented QoS technology, $GoS^{\mathbb{M}}$, which delivers reliable Quality of Service. GoS is an advanced QoS solution designed for the convergence of voice and other real-time services with data traffic. Configuring GoS on the ICAD80 ensures optimum control and performance of your applications.

GoS

GoS is based on network layers 3 and above. ICAD80 also supports Layer 2 QoS, which allows the user to prioritize LAN traffic as it enters the device. For Layer 2 information, see "Configuring Layer 2 QoS" on page 115.

GoS can be configured for the following:

Manage Contention

In typical installations the ICAD80 is deployed at the customer premises, at the boundary between the high bandwidth LAN and the lower bandwidth WAN. Network contention occurs at this point, where traffic traverses from Fast Ethernet to the WAN connection.

Voice Traffic Protection

Voice streams in particular are sensitive to quality degradation. Real-time calls cannot tolerate high packet delay (and to a lesser extent high packet loss) and must therefore be appropriately prioritized as they are forwarded onto the WAN. GoS is integrated with the Session Controller for automatic control of the QoS allocation for voice traffic as calls are established. For information about Session Controllers, see "Configuring SIP Session Controller" on page 176 and "Configuring MGCP Session Controller" on page 209.

Configuring QoS

Configuring QoS requires three steps:

1 Configuring QoS Links

A QoS link defines the portion of bandwidth managed by GoS for a specified interface. For example, to manage all of the bandwidth for a Fast Ethernet link, a QoS link would be configured for the maximum rate of 100Mbps.

2 Configuring Quality Groups

Within a Quality Group, traffic is managed as a single unit. No distinction is made between packets, streams, or flows within a Quality Group; all traffic in a Quality Group must share the Group's allocated bandwidth and quality. This can allow one, ill-behaved, out-of-contract stream to adversely affect the throughput of all other streams within that group.

When necessary, different streams can be isolated from each other: contained in separate Quality Groups. Quality Groups are used to group traffic streams with similar quality requirements and to apply the appropriate quality treatment to them.

A Quality Group is an aggregate of one or more traffic types that have similar quality requirements. Quality Groups have parameters to assign the quality treatment. These involve the allocation of loss and delay priorities (through 10 GoS Classes) and the allocation of bandwidth (using two types of policers,):

GoS Classes

A1, A2, A3, B1, B2, B3, C1, C2, C3 and BE allow the independent specification of loss and delay priorities to Quality Groups to be assigned different priorities relative to one another. See Figure 3 on page 161.

A1 represents minimum loss of packets and minimum delay: highest priority. To ensure guarantee of service can be provided, this class should only be assigned to the most critical data.

1-3 represent packet delay; typically, this is more acceptable for data than voice. The importance of each data stream must be considered; it may be necessary to minimize delay.

A-C represent the packet loss; typically, this is more acceptable for voice than data. The importance of each voice stream must be considered; it may be necessary to minimize loss. BE represents best effort, a default setting that provides the lowest priority of all traffic. Within the BE group, all packet streams are given equal weight, wih full access to the bandwidth the prioritized groups are not using. A BE group has the lowest priority.

. Policing

(CAR and Policed) allows the allocation of bandwidth either to a strictly enforced limit (policed), or with an additional burst parameter (randomised gaps between packets), permitting available bandwidth to be taken to an upper limit (CAR).

Strict policing allows the network administrator to set an absolute limit for traffic in this Quality Group (its rate). Traffic arriving at a rate below this level is allowed through, and receives the loss and delay priority treatment assigned to the QG. Traffic arriving above the configured rate is discarded. This bandwidth is guaranteed to be available to the QG whenever it is demanded.

CAR (committed access rate) policing provides a way for traffic in this Quality Group to "reuse" bandwidth that is assigned to other Quality Groups but is currently not in use. This bandwidth is made available on a best-effort basis; it is not regulated, and is treated with the lowest loss and delay priority.

3 Configuring Traffic Classification (security policy)

Security Policies are used to identify incoming traffic, map the traffic to Quality Groups, and activate the QoS configuration.

Configuring QoS Links

This section provides guidelines to configure QoS links. A QoS link specifies on which interface traffic management is required.

Configuration Requirements

Rates take into account the Ethernet header without FCS.

Constraints and Recommendations

Apply QoS links only to WAN interfaces (eth0, vif, or fr); although this can be done, QoS is typically used to manage high bandwidth links.

See "Constraints and Limitations" on page 165.

Configuration Commands

NPE> config qos link

Table 63 describes the parameters for config qos link.

 Table 63
 QoS Link Configuration Parameters

Parameters	Description
[if]	The egress interface that this link applies to (eth0 eth1 vif0)
max	The speed of the link in bps
comment	An optional comment for this link

Configure QoS Link

This example configures the QoS link as follows: Output interface (WAN): eth0 Maximum speed (Ethernet bandwidth, Mbps): 1.5 Comment (description of link): "office link"

1 Enter the following command:

NPE> config qos link eth0 max 1500000 comment "Office link"

2 To save the configuration, enter: *NPE*> save

Show QoS Link

- To show the results of the configuration, enter the following: NPE> show gos link
- The display will be similar to the following:

QoS Links	:	
Interface	Max	Comment
eth0	1500000	Office link

Remove QoS Link

NOTE: To remove a QoS link, all Quality Groups must be removed.

This example removes QoS link eth0.

- 1 Enter the following command:
 - NPE> del qos link eth0
- 2 To save the configuration, enter:

NPE> save

Configuring Quality Groups

This section provides guidelines to configure Quality Groups. A Quality Group is the definition of a QoS treatment, including bandwidth, loss, and delay parameters.

Configuration Requirements

A QoS link must exist.

When a QoS link is created, a default Quality Group assigned to BE (best effort) is automatically set up; traffic is not prioritized. This Quality Group is not displayed; however it always exists and manages the traffic flows which are not assigned to any Quality Groups.

A Quality Group can be explicitly assigned to BE, in which case it replaces the hidden BE. Functionally, nothing has changed, other than the BE Quality Group become visible.

The sum of the specified committed rates for all the Quality Groups must total no more than 90% of the link rate. 10% of link capacity is reserved for Best Effort traffic.

Configuration Commands

NPE> config qos group

Table 64 describes the parameters for config qos group.

Parameter	Description
[name]	The name of the quality group
link	The interface of the link
da	The GoS TM 2.0 class (A1 A2 A3 B1 B2 B3 C1 C2 C3 BE)
	Refer to "Quality Guaranteed Class" on page 161.
type	The type of the policer (car policed besteffort)
committed	The committed rate for a Quality Group
	The maximum rate setting is 90% of the total link rate
burst	The burst rate (ignored when Type = police)
	The burst rate should be greater than the committed rate and less than or equal to the link rate.
iptoS	Decimal IP ToS value to write into packets in this quality group (no to disable)
	Allowed values are 0-255 none

Table 64 QoS Group Configuration Parameters

Table 64	QoS Group Configuration Parameter	ers (continued)
----------	-----------------------------------	-----------------

Parameter	Description
COS	IEEE 802.1p value to write into packets in this quality group if VLAN ("no" to disable). Allowed values are no $\mid 0 \mid 1 \mid 2 \mid 3 \mid 4 \mid 5 \mid 6 \mid 7$

NPE> config protocol arp qg

protocol arp qg is used to protect ARP traffic from self to WAN.

Table 65 describes the parameter for protocol arp qp.

Table 65 Protocol ARP Parameter

Parameter	Description
dā	The GoS 2.0 Quality Group

Quality Guaranteed Class

Figure 3 summarizes the class values that can be allocated to quality groups. A1 indicates the highest class that can be allocated: low loss and low delay. BE indicates Best Effort; the best available resources will be utilized. With BE, there is no prioritization for a guaranteed level of quality.

For more information about guaranteed class, see Appendix I, "GoS Functionality".





Configure Quality Group

Example 1

This example configures a Quality Group for handling high priority VoIP traffic: Name of group: VoIP Quality group class: A1 Type of policer: policed Commitment rate: 500000 (500 kbps)

1 Enter the following command:

NPE> config qos group VoIP qg A1 type policed committed 500000

2 To save the configuration, enter:

NPE> save

Example 2

This example configures a Quality Group for handling low priority data traffic:

```
Name of group: Data
Quality group class: A3
Type of policer: CAR
Committed rate: 850 000 (850 kbps)
Burst rate: 1500000 (1.5 Mbps)
```

1 Enter the following command:

NPE> config qos group Data qg A3 type CAR committed 850000 burst 1500000

2 To save the configuration, enter:

NPE> save

Show Quality Group

- To show the results of the configuration, enter the following command: NPE> show gos group
- The display will be similar to the following:

QoS Quality Groups:

Name	Link	QG	Туре	Committed		Burst	IPT	'oS	COS
VoIP	eth0	A1	policed	500000	0	nc)	no	
Data	eth0	A3	car	1000000		1500000	no		no

Remove QoS Group

To remove a QoS group, all the traffic flows assigned to it must be removed.

The following example removes the QoS group Data:

1 Enter the following command:

NPE> del qos group Data

2 To save the configuration, enter: *NPE*> save

Configuring Traffic Classification

This section provides guidelines to configure the traffic classification to assign traffic flows to Quality Groups.

If the incoming traffic does not match any entry of the classifier, it is managed by the default Quality Group assigned to BE (Best Effort).

Configuration Requirements

At least one Quality Group must exist.

Traffic classification is accomplished by re-using the command of the security policies; the traffic classification for QoS and Security is the same.

Configuration Commands

NPE> config security policy

Table 66 describes the parameters for config security policy.

Table 66 Traffic Classification Policy Parameters

Parameter	Description
[index]	Unique numeric identifier, accepts 'new' for new policy creation
from	Where the packet originated from (self eth0 eth1)
to	Where the packet is destined to (i.e.: interface) (self eth0 eth1)
sip	The source IP or range of IP addresses
dip	The destination IP or range of IP addresses
sport	The source port or range of ports
dport	The destination port or range of ports
proto	The protocol to which the policy applies (udp tcp icmp any)
nat	NAT Policy to apply
qosqg	The GoS 2.0 quality group
iptoS	IP ToS value (decimal byte) to match ("any" to disable)
seq	Sequence of the policy (Begin End Position)
action	Whether to allow or deny traffic or disabled policy (allow deny)

Additional information follows:

- from, to, sip, dip, sport, dport, proto, iptos
 These parmaeters configure traffic classification.
- dozab

Assigns traffic to a Quality Group.

[index], nat, ipsec, seq, action
 These parameters do not affect QoS functions.

Configure Traffic Classification

Example 1

This example configures VoIP traffic sent from LAN IP address 10.0.1.100 to WAN IP address 192.168.134.100 to be protected by the Quality Group VoIP:

1 Enter the following command:

NPE> config security policy new from eth1 to eth0 sip 10.0.1.100 dip 192.168.134.100 proto udp qosgp VoIP

2 To save the configuration, enter:

NPE> save

Example 2

This example configures SNMP traffic sent from the SNMP agent of the ICAD80 to a SNMP client located in WAN IP address 192.168.134.101, to be managed by the Quality Group Data.

1 Enter the following command:

NPE> config security policy new from self to eth0 sport 161 dip 192.168.134.101 proto udp qosgp Data

2 To save the configuration, enter:

NPE> save

Show Traffic Classification

- To show the results of the configuration, enter the following:
 NPE> show security policy
- The display will be similar to the following:

Id	Seq	From	Source IP	Dest IP	Source	Dest	Proto	NZ	AT QoS
		То					Actic	n	ToS
1	1	ethl	10.0.1.100	192.168.134.100	any	any	udp	0	VoIP
		eth0					allow	7	any
2	1	self	any	192.168.134.101	161	any	udp	0	Data
		eth0					allow	7	any

Remove Traffic Classification

This configuration removes traffic classification (security policy) 1.

1 Enter the following command:

NPE> del security policy 1

2 To save the configuration, enter: *NPE*> save

QoS Statistics

This section provides examples to monitor the QoS mechanisms. Two types of statistics are available:

- Cumulative statistic, incremented over time since the last clearing.
- Instantaneous statistics, calculated over one second.

Cumulative Statistics

Following are examples to display and clear cumulative counters.

Show Statistics

- To show counters for the Quality Group VolP, enter:
 NPE> stats gos counters VoIP
- The display will be similar to the following:

Name	VoIP
Link	eth0

Packets in:	2572
Primary packets out:	2572
Downgraded packets:	0
Packets dropped:	0
Bytes in:	278950 bytes
Primary bytes out:	278950 bytes
Bytes dropped:	0 bytes
Bytes downgraded:	0 bytes

Table 67 describes the parameters of stats qos counters.

Parameter	Description
Packets in	The total number of packets received
	This is the number of packets offered to the Quality Group.
Primary	The total number of packets forwarded on the primary output
packets out	¹ This is the number of packets protected forwarded by the Quality Group.
	This represents what has been committed.
Downgraded	The total number of packets downgraded
packets	This is the number of packets non protected forwarded by the Quality Group. This only applies to Quality Groups defined as CAR.
	This represents bursts over commitments.
Packets	The total number of packets dropped
dropped	In the case of a Quality Group defined as POLICED this is the number of packets dropped because they have been received at a speed over what is committed.
	In the case of a Quality Group defined as CAR this is the number of packets dropped because they have been received at a speed over the burst rate.
Bytes in	The total number of bytes received
	This is the number of bytes offered to the Quality Group
Primary	The total number of bytes forwarded on the primary output
bytes out	¹ This is the number of bytes protected forwarded by the Quality Group.
	It represents what has been committed.
Bytes	The total number of bytes downgraded
downgraded	¹ This is the number of bytes non protected forwarded by the Quality Group.
	This only applies to Quality Groups defined as CAR. This represents bursts over commitments.
Bytes	The total number of bytes dropped
dropped	In the case of a Quality Group defined as POLICED, this is the number of bytes dropped because they have been received at a speed over what is committed.
	In the case of a Quality Group defined as CAR, this is the number of bytes dropped because they have been received at a speed over the burst rate.

Table 67 QoS Cumulative Statistics

Constraints and Limitations

The following should be considered when configuring QoS contracts.

- For a Quality Group defined as CAR, the traffic received between the committed rate and the burst
 rate is downgraded; traffic is forwarded by the Quality Group to the Quality Group assigned to BE.
 Assigned to BE, traffic is forwarded if bandwidth available. If bandwidth is in full use, the traffic is
 discarded; forwarding downgraded traffic is not guaranteed.
- Dropping packets/bytes indicates the offered load is out of contract. Traffic received over the committed rate for a Quality Group defined as POLICED or over the burst rate for a Quality Group defined as CAR is discarded. This ensures *not* forwarding more than what is guaranteed.
- Dropping packets is typically due to peak traffic; however, it may also occur due to an incorrect estimate, such as offered loads. For example, a Quality Group can be sized to protect 10 VoIP calls, when in actuality, up to 15 VoIP calls can be setup simultaneously. In this case, the size of the Quality Group should be updated accordingly.
- In some scenarios, GoS may drop packets when the average theoretical throughput of the flow is within contract. This is because the traffic source is bursting and packets are being deterministically dropped.
- Bytes take into account the Ethernet header without FCS.

Clearing Counters

Example 1

- 1 To clear the QoS statistics of the Quality Group VolP, enter the following command: NPE> clear gos counters VoIP
- 2 To save the configuration, enter: *NPE*> save

Example 2

- 1 To clear the QoS statistics of all Quality Groups, enter the following command: NPE> clear gos counters all
- 2 To save the configuration, enter:

NPE> save

Instantaneous Statistics

Following are examples to display instantaneous counters.

- To show counters for the Quality Group VolP, enter the following command: NPE> stats gos group VolP
- The display will be similar to the following:

	-
Name	VoIP
Link	eth0
Input rate:	448 bps
Output rate:	448 bps
Primary output rate:	448 bps
Downgrade output rate:	0 bps
Packet loss rate:	0 pps
Data loss rate:	0 bps
Packet loss ratio:	0 % packets lost
Data loss ratio:	0 % bytes lost
Average packet size:	56 bytes

Statistics are provided over one second. Rates and bytes take into account the Ethernet header without FCS. Table 68 describes the statistics of stats qos group.

Parameter	Description
Input rate	The input rate
	This is the offered rate to the Quality Group.
Output rate	The output rate
	This is the total output rate of the Quality Group.
Primary output rate	Primary output rate
	This is the output rate of the protected traffic.
Downgrade output	Downgrade output rate
rate	This is the output rate of the non-protected traffic. This only applies to a Quality Group defined as CAR.
Packet loss rate	Packet loss rate
	This is the rate of packets dropped by the Quality Group. In the case of a Quality Group defined as POLICED this concerns packets dropped because they have been received at a speed over what is committed. In the case of a Quality Group defined as CAR this concerns packets dropped because they have been received at a speed over the burst rate.
Data loss rate	Data loss rate
	This is the rate of bytes dropped by the Quality Group. In the case of a Quality Group defined as POLICED this concerns bytes dropped because they have been received at a speed over what is committed. In the case of a Quality Group defined as CAR this concerns bytes dropped because they have been received at a speed over the burst rate.
Packet loss ratio	Packet loss ratio
	This is the ratio of packets dropped by the Quality Group.
Data loss ratio	Data loss ratio
	This is the ratio of bytes dropped by the Quality Group.
Average packet size	Average packet size
	This is the average size of the packets handled by the Quality Group.

Table 68 QoS Instantaneous Statistics

11 MGCP CONFIGURATION

This chapter provides configuration examples for the MGCP Session Controller and the MGCP User Agent.

Introduction

The ICAD80 can be configured as both VoIP Session Controller and User Agent. The Media Gateway Control Protocol (MGCP) Session Controller controls logical links—requests from endpoint devices. The MGCP User Agent, which operates behind the Session Controller, interfaces the VoIP Gateway and analog terminals. In use, many of the endpoints (terminals) are IP telephones controlled through the Session Controller.





MGCP Session Controller

The MGCP Session Controller can handle 1000 VoIP terminal accounts and 500 concurrent calls. Traffic can be directed through the Session Controller, allowing all VoIP calls to be controlled. All VoIP devices on the local internal network, LAN, are isolated from the external network, WAN. The following services are available:

- Relay the allowed MGCP messages to the proper destination. It relays incoming messages from the Media Gateway Controller (MGC) in WAN to Media Gateway (MG) or MGCP phone, or vice versa. All the relayed messages have the source address and port as the IP address and port of the Session Controller. The MGCP SC has a transparency behavior.
- Perform the following "Keep-alive" functions:
 - ¹ If the Call Server should not receive "Keep-alive" messages, the Session Controller filters out those messages.
 - If the Call Server requires "Keep-alive" messages but a LAN endpoint does not do so, Session Controller generates those packets for the endpoint device.
- Overwrite the media session information in SDP so that media streams go through the ICAD80 or avoid it (direct media connection, for LAN to LAN calls only).
- Track device status on the LAN to know when a LAN endpoint goes down (using AUEP requests). If the Session Controller is rebooted, maintain information of the device; re-registration is not necessary.
- Reject call requests if a LAN endpoint is not allowed to make calls according to Access List Control (ACL) rules.
- Reject call requests if a LAN endpoint is not registered (RSIP).
- Reject call requests from either a LAN endpoint or the MGC, if the Session Controller fails to allocate bandwidth for the call, according to the Call Admission Control (CAC).
- Monitor voice quality.

The MGCP Session Controller supports the local call routing: when all MGCP servers are down, the MGCP SC still routes local calls and optionally routes calls to the PSTN network. For more information about local call routing, see Chapter 12, "VoIP Survivability".

MGCP User Agent

The FXS port of ICAD80 can be configured as a MGCP User Agent (MGCP UA) port, enabling VoIP communication with analog and IP terminals.

The MGCP User Agent (MGCP UA) interfaces VoIP to POTS (Plain Old Telephone System—analog), and functions as a VoIP Gateway, connecting an analog phone, modem or FAX machine to the MGCP network.

MGCP User Agent Features

MGCP UA supports the following features.

- MGCP User Agent functions as an MGCP integrated access device (IAD).
- Digit Maps

MGCP UA works with Call Server's digit maps to initiate calls after enough digits have been received from the analog interface, instead of waiting for timeout.

- Analog telephone features are supported—MGCP UA detects hook flash in FXS and reports the event to Call Agent (CA). The features include:
 - Call onhold / retrieve
 - Make / receive second call
 - ⁿ Call transfer
 - ⁿ 3-way conference
 - Call Waiting notification

Configuring MGCP Server

This section provides guidelines to configure the MGCP servers.

Up to 3 MGCP servers can be configured. They must be set manually.

Each MGCP server has a priority. When the manual mode is selected, the priorities are as follows:

- mgc1: highest priority 0
- mgc2: priority 1
- mgc3: lowest priority 2

The MGCP SC uses priorities to implement a failover mode; when the current MGCP server goes down, the MGCP SC tries to use the alternative servers.

When MGCP servers are configured, the Firewall is automatically updated to accept MGCP messages from those MGCP servers.

To configure the MGCP features of the ICAD80, the following steps are required:

- 1 Configuring MGCP servers
- 2 Configuring MGCP Session Controller
- 3 Configuring MGCP User Agent and other LAN MGCP phones

Configuration Requirements

The MGCP servers should be reachable.

Configuration Commands

NPE> config mgcp server settings

Table 83 describes the parameters for config mgcp server settings.

Table 83 MGCP Server Configuration Parameters

Parameter	Description
[name]	Name of the settings profile
mgc1	The 1st media gateway controller (Name IP)
port1	The 1st media gateway controller's port
mgc2	The 2nd media gateway controller (Name IP)
port2	The 2nd media gateway controller's port
mgc3	The 3rd media gateway controller (Name IP)
port3	The 3rd media gateway controller's port
retries	Number of retries before blacklisting MGC (0 to disable)
blacklist	Blacklist timer in seconds

Configure MGCP Server

This example configures a single MGCP server as follows:

Name: Sylantro MGC server: 206.229.26.51 MGC server port: 2727

1 Enter the following command:

NPE> config mgcp server settings Sylantro mgcl 206.229.26.51 portl 2727

2 To save the configuration, enter the following:

NPE> save

Configure Failover Mode

The failover mode is available when two or more MGCP servers are configured; the MGCP servers must be synchronized.

When the failover mode is not activated, the MGCP SC communicates with the MGCP server of highest priority. If the MGCP server goes down, the MGCP SC continuously retries to contact it. In this scenario, to establish calls, the MGCP SC must wait until the server recovers.

When the failover mode is activated, the MGCP SC automatically detects that a MGCP server is down: if it does not have IP connectivity with it (WAN interface unplugged, no IP route, etc.) or if it receives no MGCP replies from it.

The latter case can be configured with the parameter retries. It configures the number of retries before considering the MGCP server down. If this occurs, the MGCP server is marked as down by the MGCP SC for the duration configured by the parameter blacklist; the MGCP SC will not retry to contact it during this period of time. Instead the MGCP SC tries to communicate with the next MGCP server of highest priority. When the period of time expires for a MGCP server marked as down, the MGCP SC tries to resume the MGCP communications with it.

NOTE: The period of time during which a MGCP server is considered down starts when the MGCP SC detects it. This period of time is independent for each MGCP server marked as down.

This example configures the failover mode as follows:

Name: Sylantro_FailOverMode
Mgc1: primary.sylantro.com
Port1: 2727
Mgc2: secondary.sylantro.com
Port2: 2727
Retries: 10
Blacklist: 300

1 Enter the following command:

```
NPE> config mgcp server settings Sylantro_FailOverMode mgc1
primary.sylantro.com port1 2727 mgc2 secondary.sylantro.com port2 2727
retries 10 blacklist 300
```

2 To save the configuration, enter the following:

NPE> save

Show Configuration

- To show the results of the configuration, enter the following:
 NPE> show mgcp server settings
- The display will be similar to the following:

MGCP Server "Sylantro":

Sylantro
206.229.26.51
2727
2727
2727

```
7
   Retries
   Blacklist 600 sec
MGCP Server "Sylantro_FailOverMode":
              Sylantro_FailOverMode
   Name
   MGC1
              primary.sylantro.com
   Port1
              2727
   MGC2
              secondary.sylantro.com
              2727
   Port2
   MGC 3
   Port3
              2727
   Retries
              10
   Blacklist 300 sec
```

Show Status

The following example shows the status of the MGCP server.

- To show the status of the MGCP server, enter the following:
 NPE> show mgcp server status
- The display will be similar to the following: MGCP Server "Sylantro_FailOverMode":

Name	Sylantro_FailOverMode
Active	Yes
MGC1	primary.sylantro.com (In-use)
Port1	2727
MGC2	<pre>secondary.sylantro.com (Ready)</pre>
Port2	2727
MGC3	
Port3	2727

Following are descriptions of the information fields:

Active

Reports if at least one MGCP server is active:

- " Yes: the status is active, the MGCP SC normally communicates with a MGCP server.
- No: the status is down, the MGCP SC does not communicate with any MGCP server.
- MGC1, MGC2, MGC3

Report which MGCP server is currently used is the field Active is Yes.

- In-use: the MGCP server is currently active and used.
- Ready: the MGCP server is not used.

The remaining information is extracted from the configuration (manual or automatic).

Configuring MGCP Session Controller

This section provides guidelines to configure the MGCP Session Controller (MGCP SC).

The MGCP Session Controller provides the following features:

Relays MGCP messages between MGCP endpoints and MGCP servers (MGCP Signaling Proxy or MSP).

NOTE: The MGCP SC only supports endpoint identification endpoint@domain-name in which domain-name is a MAC address. It does not support identification per IP address.

- Controls how VoIP media traffic is established (Media BRidge: MBR)
- Controls which LAN endpoints can place/receive calls (Access Control List: ACL)
- Controls the status (i.e. up or down) of LAN endpoints (Endpoint Status Handling: ESH)
- Controls if LAN endpoints can place/receive calls (Call Admission Control: CAC).
- Reports the quality of calls (Voice Quality Monitoring: VQM).

MGCP Signaling Proxy (MSP)

Configuration Requirements

A MGCP server must be configured. See "Configuring MGCP Server" on page 207.

A QoS Quality Group must be configured to protect the MGCP signaling traffic. See "Configuring Quality Groups" on page 160.

Configuration Commands

NPE> config mgcp sc settings

Table 84 describes the parameters for config mgcp sc settings.

Parameter	Description
server	Profile name of the MGCP call server
wanrxport	Signaling Rx port on WAN side
lanrxport	Signaling Rx port on LAN side
keepalive	Time period sending keep-alive to MGC 0 means no sending
eptimeout	Timeout of an active LAN endpoint time for keep-alive checking
maxcalls	Call Admission Control, maximum calls allowed
sigqos	GoS 2.0 quality group for signaling

Table 84 MGCP Session Controller Configuration Parameters

Configure MGCP Signaling Proxy (MSP)

The MGCP Signaling Proxy (MSP) is configured with the command config mgcp sc settings, which specifies how the MGCP signaling is relayed.

server

How to modify MGCP headers to be relayed.

wanrxport, lanrxport

On which ports to listen MGCP signaling messages on LAN and WAN.

∎ sigqos

Which QoS Quality Group to protect MGCP signaling from other traffic. MGCP signaling is sensitive traffic. If MGCP packets are dropped, calls can fail.

 keepalive
 If the MGCP server requires "Keep-alive" messages to be sent from LAN endpoints, the MGCP SC can still send those messages if they are not supported

This example configures the MGCP Signaling Proxy as follows:

MGCP server: Sylantro
WAN RX port: 2427 LAN RX port: 2427 Signaling QoS: VoIP

1 Enter the following command:

```
NPE> config mgcp sc settings server Sylantro wanrxport 2427 lanrxport 2427 sigqos VoIP
```

2 To save the configuration, enter:

NPE> save

Show Configuration

- To show the results of the configuration, enter the following command:
- NPE> show mgcp sc settings
- The display will be similar to the following: MGCP Session Controller settings:

Server	Sylantro
Wan Rx Port	2427
Lan Rx Port	2427
Keep Alive	0 sec
EP Timeout	3600 sec
Max Calls	500
Signaling QoS Group	VoIP

Show Status

- To show the status of the MGCP Signaling Proxy, enter the following command: NPE> show mgcp sc status
- The display will be similar to the following:

MGCP Session Controller status:

MSC Started	Yes
MSC Server Ready	Yes
My Wan IpAddr	192.168.134.217
Wan Rx Port	2427
Lan Rx Port	2427
CAC Max Calls	500

Following are descriptions of the information fields:

- MSC Server Ready
 - " Yes: MGCP server is active
 - ⁿ No MGCP: server is not active

The remaining information is extracted from the configuration.

Show Statistics

Example 1

The following example displays the statistics of the MGCP signaling packets relayed.

 To show the statistics of the MGCP signaling relayed, enter the following command: NPE> stats mgcp sc status

• The display will be similar to the following:

MGCP Session Controller message stats:

Msg per sec. (current/highest):	0/0
TotalMsgRxCount	0
RxMsgDropSrcErr	0
RxMsgDropIntErr	0
RxMsgDropNoBufErr	0
RxMsgDropWanCsErr	0
RxMsgDropWanIfErr	0
TxMsgDropNoBufErr	0
TxMsgDropIntErr	0
WanMsgRecvCount	0
WanMsgProcCount	0
WanMsgDropDataErr	0
WanMsgDropNoBufErr	0
WanCmdCacRejErr	0
WanCmdDropSecFail	0
WanCmdDropDataErr	0
WanRspDropDataErr	0
WanRspDropStateErr	0
LanMsgRecvCount	0
LanMsgProcCount	0
LanMsgDropDataErr	0
LanMsgDropSecErr	0
LanMsgDropNoBufErr	0
LanCmdEacRejErr	0
LanCmdCacRejErr	0
LanCmdDropSecFail	0
LanCmdDropDataErr	0
LanRspDropDataErr	0
LanRspDropStateErr	0

Following are descriptions of the information fields:

WanMsgRecvCount, WanMsgProcCount, LanMsgRecvCount, LanMsgProcCount
 Report normal relaying.

All other fields report errors.

Example 2

The following example displays the statistics of MGCP calls.

- To show the statistics of the MGCP calls, enter the following command: NPE> stats mgcp sc calls
- The display will be similar to the following: MGCP Session Controller call stats:

Call per sec. (current/highest):	0/0
Active calls (current/highest):	0/0
Total calls attempted:	0
Total outbound calls from LAN: Calls on going: Calls succeeded: Calls failed:	0 0 0 0
- Call rejected no bandwidth: - Call cancelled: - Called dest busy: - Others causes:	0 0 0 0
Total inbound calls from WAN: Calls on going: Calls succeeded: Calls failed: - Call rejected no bandwidth: - Call cancelled:	0 0 0 0 0
- Called dest busy: - Others causes:	0

The calls from LAN are the calls originated from LAN endpoints. The calls from WAN are the calls originated from the MGCP server.

NOTE: A LAN to LAN call is both a call originated from a LAN endpoint and a call originated from the MGCP server.

Media BRidge (MBR)

Configuration Requirements

A QoS Quality Group must be configured to protect the VoIP media traffic. For more information about QoS refer to "Configuring Quality Groups" on page 160.

The RTP range must contain at least 1000 values and must not overlap any existing services of the ICAD80.

Configuration Commands

NPE> config media settings

Table 85 describes the parameters for config media settings.

Table 85 Media Configuration Parameters

Parameter	Description	
dm	Enable use of direct media/RTP between 2 endpoints	
rtp	Range of RTP ports to use (syntax: 'RTP low#-high#')	
medqos	GoS 2.0 quality group for media streams	
maxqos	Max number of media connection (streams) allow	

Configure Media BRidge (MBR)

Media BRidgespecifies how the VoIP media traffic is established:

- If LAN to LAN communications must be bridged by the ICAD80, or must be established directly between the parties.
 - n dm
- Which values to use as destination and source UDP ports, respectively for the LAN and WAN side of the ICAD80. This values can be used by ISP access routers as criteria to classify media traffic in order to apply QoS actions.

```
n rtp
```

Which QoS Quality Group to protect VoIP media traffic. VoIP media traffic is very sensitive. If VoIP media packets are dropped or are delayed, voice quality can be poor.

```
" medqos
```

This example configures the Media BRidge as follows:

```
Direct Media: yes
RTP range: 10000-12000
Media QoS: VoIP
```

1 Enter the following command:

NPE> config media settings dm yes rtp 10000-12000 medqos VoIP

2 To save the configuration, enter:

```
*NPE*> save
```

Show Configuration

- To show the results of the configuration, enter the following command: NPE> show media settings
- The display will be similar to the following:

Media config:

DM Enabled	Yes
RTP Ports	10000 - 12000
MedQoS	VoIP
MaxConn	500

Show Status

- To show the status of the Media BRidge, enter the following command: NPE> show media status
- The display will be similar to the following:

Media status:

```
Max. cap (max_conn/qos_bps):500/89000000Port usage (current/highest):0/0Conn usage (current/highest):0/0Rate usage (current/highest):0/0
```

Following are descriptions of the information fields:

- port usage
 Reports the current number of ports used and the highest port.
- conn usage
 Reports the current number of VoIP connections and the highest connection.
- rate usage

Reports the current VoIP media rate and the highest media rate.

Show Statistics

The following command displays the list of MGCP calls established by the Media BRidge.

- To show the list of MGCP calls established by the Media BRidge, enter the following command: NPE> show mgcp sc calls
- The display will be similar to the following:
 MGCP Session Controller detailed call entries:

Call Info	Call to: 6019
EP Info	4083747001@001122334455, 127.0.0.1:0
Line Number	1
Line State	CALL_CONNECTED
Media Conn Mode	NORMAL
Media Type	AUDIO
Media Conn_b	66.206.164.199:3204666.206.164.203:13024<==
Media Conn_a	==>127.0.0.1:13024127.0.0.1:32100
	Call Info EP Info Line Number Line State Media Conn Mode Media Type Media Conn_b Media Conn_a

The following command displays the list of VoIP media connections established by the Media BRidge.

 To show the list of VoIP media connections established by the Media BRidge, enter the following command:

NPE> show media connection

 The display will be similar to the following: SMedia Connections:

From IP (In)	To IP (In)	From IP (Out)	To IP (Out)	Mode
Port	Port	Port	Port	
10.0.20.2	10.0.1.1	172.29.250.5	172.29.250.30	Bridge
29268	13006	13006	29490	
10.0.20.2	10.0.1.1	172.29.250.5	172.29.250.30	Bridge
29269	13007	13007	29491	

Access Control List (ACL)

Configuration Requirements

CDP must run on the ICAD80.

Configuration Commands

NPE> config voice acl

Table 86 describes the parameters for config voice acl.

	Table 86	Voice ACL	Configuration	Parameters
--	----------	-----------	---------------	------------

Parameter	Description
[id]	Unique numeric identifier, accepts 'new' for new policy creation
mac	MAC address of the endpoint
epid	ID of the endpoint

Parameter	Description	
softversion	Software Version of the endpoint	
platform	Platform type of the endpoint	
deviceid	Device Id of the endpoint	
seq	Sequence number of the policy (begin end position)	
ip	Single or a range of addresses of the endpoints	
type	Signalling type for the endpoint (any mgcp sip)	
action	Access (Deny or Allow)	

Table 86 Voice ACL Configuration Parameters (continued)

Configure Access Control List (ACL)

The Access Control List (ACL) is configured with the command config voice acl. It specifies which LAN endpoints are allowed to place/receive calls. Authentication is based on the following information:

- MAC address
- IP address
- Signaling Type
- Device ID
- Endpoint ID
- Platform
- Software version

The MAC address, IP address, and Signaling Type are discovered by the MGCP SC; the other information is discovered by the Cisco Discovery Protocol (CDP). For information about CDP, see "Cisco Discovery Protocol (CDP)" on page 300.

By default, Access Control List allows all LAN endpoints to place/receive calls. If omitted parameters for classification are set to "any", which means that all values match. If omitted the action is "allow".

This example configures the Access Control List as follows:

IP address: 10.0.1.100 Signaling type: MGCP Device ID: MGC000F8F073088 Action: deny

1 Enter the following command:

NPE> config voice acl new ip 10.0.1.100 type mgcp deviceid MGC000F8F073088 action deny

2 To save the configuration, enter:

NPE> save

Show Configuration

- To show the results of the configuration, enter the following command: NPE> show voice acl
- The display will be similar to the following:

Id S	Seq	EpId	Platform	IP	MAC Address	Action
		Software	DeviceId		Туре	Stats
1	 1	any anv	any MGC000F*	10.0.1.100	any mgcp	deny 0

stats

Reports the number of times the policy matched.

Endpoint Status Handling (ESH)

Configuration Requirements

There are no requirements to configure Endpoint Status Handling.

Configuration Commands

NPE> config mgcp sc settings

Table 87 describes the parameters for config mgcp sc settings.

Tahle 87	MGCP Session	Controller	(ESH)	Config	uration	Parameters
I able 01	WIGGE SESSION	Controller	(ESH)	Connig	urauon	raiaiiieieis

Parameter	Description
server	Profile name of the MGCP call server
wanrxport	Signaling Rx port on WAN side
lanrxport	Signaling Rx port on LAN side
keepalive	Time period sending keep-alive to MGC 0 means no sending
eptimeout	Timeout of an active LAN endpoint time for keep-alive checking
maxcalls	Call Admission Control, maximum calls allowed
sigqos	GoS 2.0 quality group for signaling

Configure Endpoint Status Handling (ESH)

The Endpoint Status Handling (ESH) saves information about LAN endpoints in non-volatile memory, which can be retrieved when the ICAD80 is rebooted. This information is saved during the MGCP registration process (RSIP) of the LAN endpoints to the MGCP servers. Following is a list of the information that is stored:

- MGCP Endpoint ID
- Name
- Telephone number
- IP address
- MGCP port
- MGCP Call Agent port
- Remaining active time (based on the parameter eptimeout)

The MGCP SC rejects calls terminating LAN endpoints that are not registered to the MGCP server; these calls do not need to be re-registered should the ICAD80 reboot.

ICAD80 periodically checks the status of each LAN endpoint using the MGCP method AUEP. When a LAN endpoint answers, the timer (remaining active time) is reset to the value <code>eptimeout</code>. If the endpoint does not answer, the MGCP SC marks it as down and rejects all calls terminating it.

The following example configures the Endpoint Status Handling:

Active time: 1800 seconds

1 Enter the following command:

NPE> config mgcp sc settings server Sylantro eptimeout 1800

2 To save the configuration, enter: *NPE*> save

Show Configuration

- To show the results of the configuration, enter the following command: NPE> show mgcp sc settings
- The display will be similar to the following:

MGCP Session Controller settings:

Server	Sylantro
Wan Rx Port	2427
Lan Rx Port	2427
Keep Alive	0 sec
EP Timeout	1800 sec
Max Calls	500
Signaling QoS Group	VoIP

Show Statistics

The following command displays the list of LAN endpoints registered to the MGCP server through the MGCP SC. This list can be retrieved should the ICAD80 be re-booted.

To show the list of the LAN endpoints registered, enter the following command:

NPE> stats mgcp sc status

The display will be similar to the following:

MGCP Session Controller endpoints:

Endpoint ID	EP Addr	EP Port	Act Calls
Endpoint Name	TelNo	CA Port	Timeout
4083746017@00152b177677 Sophia 6017 4083747001@00111111111	10.0.1.57 6017 127.0.0.1 7000	2427 2432 0 2429	0 1500 0 1011

Following are descriptions of the information fields:

- Endpoint ID, Endpoint Name, IP Addr, TelNo, EP Port
- Extracted from the MGCP registration process (RSIP) of the LAN endpoints to the MGCP server. • CA Port
 - Extracted from the last MGCP message received from the MGCP server including a Notified Entity.
- Timeout

Initialized with the value eptimeout: decremented over time.

Act Calls i

Incremented when the LAN endpoint places or receives a call. Decremented when the call is torn down.

Call Admission Control (CAC)

This section provides information and configuration examples for CAC.

Configuration Requirements

A QoS Quality Group must be configured to protect the VoIP media traffic in the case Call Admission Control is set-up based on QoS. For more information about QoS refer to "QoS Configuration" on page 157.

Configuration Commands

NPE> config mgcp sc settings

Table 88 describes the parameters for config mgcp sc settings.

	Table 88	MGCP Session Con	troller (CAC) Co	onfiguration Parameters
--	----------	------------------	------------------	-------------------------

Parameter	Description
server	Profile name of the MGCP call server
wanrxport	Signaling Rx port on WAN side
lanrxport	Signaling Rx port on LAN side
keepalive	Time period sending keep-alive to MGC 0 means no sending
eptimeout	Timeout of an active LAN endpoint time for keep-alive checking
maxcalls	Call Admission Control, maximum calls allowed
sigqos	GoS 2.0 quality group for signaling

NPE> config media settings

Table 89 describes the parameters for config media settings.

Table 89 Media Configuration Parameters

Parameter	Description
dm	Enable use of direct media/RTP between 2 endpoints
rtp	Range of RTP ports to use (syntax: 'RTP low#-high#')
medqos	GoS 2.0 quality group for media streams
maxqos	Max number of media connection (streams) allow

Configure Call Admission Control (CAC)

Call Admission Control (CAC) is configured with the commands <code>config mgcp sc settings</code> and <code>config media settings</code>. They specify if a LAN endpoint can place/receive a call, as described below.

- The maximum number of MGCP calls can be established through the ICAD80.
 - maxcalls (config mgcp sc settings)
- The maximum number of VoIP media streams can be established through the ICAD80.
 - maxqos (config media settings)
 - medqos (config media settings)

A MGCP call can be rejected for three reasons:

- The maximum number of MGCP calls maxcalls is exceeded.
- The maximum number of streams maxqos is exceeded.

• The medgos refers to a QoS Quality Group and there is no more bandwidth available.

For performance, the following considerations are recommended:

- The parameter siggos should be configured to administratively limit the number of calls. It is typically defined by an ISP based on a number of users.
- The parameters maxgos and medgos should be configured to prevent call quality from deteriorating.

Calls are rejected when the WAN bandwidth dedicated to VoIP traffic is not available. In that circumstance, if all calls were accepted, exceeding the committed load for VoIP traffic, would cause VoIP packets to be dropped. As a result, the quality of all calls would be impacted. The parameters maxqos and medqos are typically based on the WAN bandwidth that is dedicated to VoIP traffic.

The parameter maxqos does not differentiate between VoIP media streams of different CODECs (so of different rates); however, the parameter medqos does.

Based on the CODEC negotiation, the MGCP SC derives how much bandwidth is required to establish the call, and checks if there is sufficient bandwidth remaining in the QoS Quality Group. Baed on that information, the SC decides whether to accept or reject the call.

 When the Call Admission Control is configured based on QoS, it is strongly recommended to select a Quality Group assigned to A1; this selection guarantee the lowest delays and the lowest percentage of packets dropped. It is strongly recommended to select a Quality Group defined as POLICED to strictly enforce the rate of the incoming traffic, which protects the calls.

For information about QoS groups, refer to Chapter 9, "QoS Configuration" and Appendix I, "GoS Functionality".

The following example configures the Call Admission Control based on QoS:

QoS Quality Group: VoIP

1 Enter the following command:

NPE> config media settings medgos VoIP

2 To save the configuration, enter: *NPE*> save

Show Configuration

- To show the results of the configuration, enter the following command: NPE> show media settings
- The display will be similar to the following:

Media config:

DM Enabled	No
RTP Ports	13000 - 14999
MedQoS	VoIP
MaxConn	500

Show Status

The following command shows the status of maxcalls.

- To show the status of the Call Admission Control for maxcalls, enter the following command:
 NPE> show mgcp sc status
- The display will be similar to the following: MGCP Session Controller status:

MSC Started

Yes

MSC Server Ready	Yes
My Wan IpAddr	192.168.134.217
Wan Rx Port	2427
Lan Rx Port	2427
CAC Max Calls	500

The field CAC Max Calls reports the maximum number of MGCP calls allowed.

The following command shows the status of maxqos and medgos.

To show the status of the Call Admission Control for maxgos and medgos, enter the following command:

NPE> show media status

The display will be similar to the following:

Media status:

Max. cap (max_conn/qos_bps):	500/1000000
Port usage (current/highest):	0/0
Conn usage (current/highest):	0/0
Rate usage (current/highest):	0/0

maximum capacity

Reports the maximum number of streams (extracted from the configuration), and the maximum available bandwidth of the QoS Quality Group managing the VoIP media traffic.

Show Statistics

The commands stats mgcp sc status and stats mgcp sc calls, described in "Show Statistics" on page 211, report statistics about the number of calls rejected because of the Call Admission Control.

For the command stats mgcp sc status, statistics are reported by through counters WanReqCacRejErr and LanReqCacRejErr.

For the command stats mgcp sc calls, statistics are reported by the counter Call rejected no bandwidth.

Voice Quality Monitoring (VQM)

Configuration Requirements

There are no requirements to configure Voice Quality Monitoring.

Configuration Commands

NPE> config calls analyzer

Table 90 describes the parameters for config calls analyzer.

Table 90 Call Analyzer Configuration Parameters

Parameter	Description
jb	Whether emulate a static of adaptive jitter buffer (static adaptive)
min	Minimum for the simulated JB
max	Maximum for the simulated JB

Parameter	Description
nom	Nominal level for simulated JB
rtdelay	Estimate of Round Trip delay if no RTCP records detected
quality	Whether the low quality alarms are enabled
burst	Whether the excessive bursting alarms are enabled
delay	Whether the excessive delay alarms are enabled
rquality	The low quality R Factor trigger
rburst	The excessive bursting R Factor trigger
minburst	The excessive bursting minimum trigger
maxdelay	The excessive delay maximum delay trigger
qalertclear	The minimum duration for the low listening quality alarm clear trigger
balertclear	The minimum duration for the excessive bursting alarm clear trigger
dalertclear	The minimum duration for the excessive delay alarm clear trigger

Table 90 Call Analyzer Configuration Parameters (continued)

Configure Voice Quality Monitoring (VQM)

The Voice Quality Monitoring (VQM) specifies how to measure call quality.

The Voice Quality Monitoring simulates a Jitter Buffer to analyze VoIP media streams, then deduce information such as packet loss, delay, jitter, etc. Based on these parameters, it calculates R-Factors/Mean Opinion Scores updated in real-time over the duration of calls. Related parameters are jb, min, max, nom and rtdelay.

- VQM specifies if alarms must be triggered for a low quality R-Factor, an excessive bursting R-factor (low quality R-factor lasting a certain period of time) and an excessive delay.
 Related parameters are respectively quality, burst and delay.
- VQM also specifies when to trigger these alarms and when to clear them.
 Related parameters are rquality, rburst, minburst, maxdelay, qalertclear, balertclear and dalertclear.

Alarms are reported in the system logging as INFORM messages. For system logging information, see Chapter 14, "Monitoring".

Voice Quality Monitoring reports statistics for VoIP media streams coming from the WAN only. For VoIP media streams coming from LAN their quality is not measured because it is assumed LANs to not suffer from network impairments as the WANs do.

Voice quality Monitoring reports statistics for the following CODECs:

- G.711 u-law
- G.711 A-law
- G.726-32k
- G.728-class
- G.729-class (but not G.729D and G.729E)
- GSM Full-Rate (6.10)

This example configures the Voice Quality monitoring as follows:

Jitter Buffer: static Alarm for low quality R-factor: yes Alarm for excessive bursting R-factor: yes Alarm for excessive delay: yes Low R-Factor: 50 Excessive bursting R-factor: 50 Excessive bursting R-factor duration: 1000ms Excessive delay: 100ms

1 Enter the following command:

NPE> config call analyzer jb static quality yes burst yes delay yes rquality 50 rburst 50 minburst 1000 maxdelay 100

2 To save the configuration, enter:

NPE> save

Show Configuration

- To show the results of the configuration, enter the following command: NPE> show call analyser
- The display will be similar to the following:

Call Analyser:

JB	Туре	sta	itic
JB	Minimum	10	
JB	Maximum	60	
JB	Nominal	30	
Roundtrip Delay		60	ms

Alarms:

Quality	yes
Burst	yes
Delay	yes
R-Quality	50
R-Burst	50
Min Burst	1000 ms
Max Delay	100 ms
Min Quality Alert Clear	3 sec
Min Burst Alert Clear	3 sec
Min Delay Alert Clear	3 sec

Show Statistics

The following command displays a summary of the quality of voice calls.

- To show a summary view of the quality of voice calls, enter the following command:
 NPE> show call quality
- The display will be similar to the following: Monitored Calls:

EP-ID	EP-Name	MOS-LQ	MOS-CQ	R Factor	RTP Rx	Loss	Codec
call.two	4982	4.20	4.18	92	515	0.00	PCMU

Following are descriptions of the information fields:

■ IP-ID, EP-Name

Report the source of the VoIP media stream monitored.

- MOS-LQ, MOS-CQ, R Factor
 Report the scores respectively for Mean Opinion Score Listening Quality, Mean Opinion Score Conversation Quality and R-Factor. These values depend on the CODEC used and on how much the traffic is disrupted through the network: packet loss, delay, jitter, etc.
- RTP Rx

Reports the number of RTP packets received from the source. The field $\tt Loss$ reports how many packets have been lost.

Codec

Reports the CODEC used by the source.

NOTE: This command does not report information if the CODEC is not a CODEC supported by Voice Quality Monitor. See "Introduction" on page 205.

The following command displays a full view of the quality of voice calls. It displays the values of the different parameters used to estimate the quality of calls (MOS and R-Factor scores).

• To show a full view of the quality of voice calls, enter the following command:

NPE> stats call quality

The display will be similar to the following:

Monitored Calls:

EP-ID	MOS-LQ	RTP Rx	JB Admit	JB Early	JB 000	JB URun
EP-Name	MOS-CQ	Lost	JB Disc	JB Late	JB Dup	JB ORun
call.tw*	4.20	884	884	1	0	0
4982	4.18	0	0	0	0	0

Following are descriptions of the information fields:

IP-ID, EP-Name

Report the source of the VoIP media stream monitored.

MOS-LQ, MOS-CQ

Report the scores respectively for Mean Opinion Score - Listening Quality, Mean Opinion Score - Conversation Quality. These values depend on the CODEC used and on how much the VoIP traffic is disrupted through the network: packet loss, delay, jitter.

RTP Rx

Reports the number of RTP packets received from the source.

Loss

Reports how many packets have been lost.

∎ JB

Reports the statistics of the Jitter Buffer simulated to deduce how much the VoIP traffic is disrupted.

NOTE: This command does not report information if the CODEC is not a CODEC supported by Voice Quality Monitor. See "Introduction" on page 205.

The following command displays alarms. Alarms are sent to the system logging. For more information about system logging, see Chapter 14, "Monitoring".

- To show the statistics about the alarms, enter the following command: NPE> show logging internal
- The display will be similar to the following:

Message

```
09:33:19: (:100001) Excessive Bursting alert on call detected
09:33:19: (:100001) Excessive Bursting alert on call cleared
```

Following are descriptions of the information fields:

- The first column shows time.
- The second column shows the source of the VoIP stream for which the alarm is triggered.
- The third column reports which alarm is detected or cleared:
 - Low Quality: low R-Factor
 - **Excessive Bursting:** excessive bursting R-factor
 - Excessive Delay: excessive delay

The following command displays statistics about the alarms. This command reports the number of alarms triggered.

- To show the statistics about the alarms, enter the following command: NPE> show call alarms
- The display will be similar to the following:

Alarm Stats:

Low Qualit	сy	б
Excessive	Burst	15
Excessive	Delay	0

Following are descriptions of the information fields:

- Low Quality
 Reports the number of alarms reported because of a low R-Factor.
- Excessive Burst
 - Reports the number of alarms reported because of an excessive bursting R-factor.
- Excessive Delay
 Reports the number of alarms reported because of an excessive delay.

Configuring MGCP User Agent

This section provides guidelines to configure the MGCP User Agent (MGCP UA).

The MGCP UA must be considered as a VoIP MGCP phone located on the LAN. It is binded to the FXS (phone) port of the ICAD80. The identifier of this port is 1. MGCP identification (domain name) is supported by MAC address only.

The MGCP UA currently supports the following features:

- CODECs G.711 u-law, G.711 a-law and G.729
- RFC 2833
- Modem pass through
- Fax pass through

To configure the MGCP UA, the following steps are recommended:

- MGCP protocol
- FXS port
- MGCP UA

MGCP Protocol

The configuration of the MGCP protocol applies to the MGCP UA only. It does not apply to the MGCP SC. The MGCP protocol can be modified for interoperability purposes within the MGCP environment.

The following changes can be applied to the MGCP protocol:

- Domain format (currently, the only one supported is by MAC address)
- The maximum number of re-transmission when a request does not get an answer
- Timer before restarting the MGCP UA in the case the MGCP server does not answer anymore

NOTE: The MGCP protocol is configured so the MGCP UA tries to get registered to the MGCP server as soon as it is started using RSIP. MGCP UA is not functional until it is registered.

Configuration Requirements

There are no requirements to configure the MGCP protocol.

Configuration Commands

NPE> config mgcp ua settings

Table 91 describes the parameters for config mgcp ua settings.

Table 91	MGCP Protocol	Configuration	Parameters
----------	---------------	---------------	------------

Parameter	Description
domainformat	Format of MGCP Endpoint Domain Names (MACAddr)
maxretxcount	Max Number of Successive Re-transmission for User Agent

Configure MGCP protocol

This example configures the MGCP protocol as follows:

Domain format: MAC address Maximum number of re-transmission: 5

1 Enter the following command:

NPE> config mgcp ua settings domainformat MACAddr maxretxcount 5

2 To save the configuration, enter:

NPE> save

Show Configuration

- To show the configuration of the MGCP protocol, enter the following command:
 NPE> show mgcp ua settings
- The display will be similar to the following:

MGCP Protocol Settings:

DomainFormat	MACAddr
MUAMaxReTxNum	10
MUARestartDelay	50000

Configure FXS Port

The considerations for configuring the FXS port are as follows:

- A country code to adjust the settings of the port to specific parameters required by the selected country. Refer to "Country Codes" on page 439.
- The type of the jitter buffer to interface the DSP: adaptive or fixed
- A DSP gain

Configuration Requirements

There are no requirements to configure the FXS port.

Configuration Commands

NPE> config system info

Table 92 describes the parameters for config system info.

Table 92 System Parameters Configuration Parameters

Parameter	Description
unit	Unit name of this box
country	ISO-3166 two letter country code

NPE> config voice jitterbuffer

Table 93 describes the parameters for config voice jitterbuffer.

Table 93 Voice Jitterbuffer Configuration Parameters

Parameter	Description
mode	Jitter Buffer Type (fixed adaptive)
maximum	Maximum delay introduced by the jitter buffer (ms), for Adaptive Mode only
nominal	Nominal delay introduced by the jitter buffer (ms), for both modes
minimum	Minimum delay introduced by the jitter buffer (ms), for Adaptive Mode only

Configure FXS Port

This example configures the FXS port as follows:

Country: US Jitter buffer: Fixed, 60ms

1 Enter the following commands:

```
NPE> config system info country US
NPE> config voice jitterbuffer mode fixed nominal 60
```

2 Save the configuration. Enter:

NPE> **save**

Show Configuration

- To show the configuration of the FXS port (country), enter the following command: NPE> show system info
- The display will be similar to the following: System Info:

Unit Name	MyUnit
Bootcode Ver	1.10.0007
App. Ver	ICAD T2 2.02.0135
System Type	NP40
Memory	79/128 MB
Country	United States of America (US)
Up time	0 days, 4 hours, 33 mins & 20 secs

 To show the configuration of the FXS port (jitter buffer and gain), enter the following command:

NPE> show voice jitterbuffer

The display will be similar to the following:

Voice Jitter Buffer Settings:

Mode	fixed
Maximum	120 ms
Nominal	60 ms
Minimum	20 ms

Show Status

The following command shows the status of the tone of the FXS port.

- To show the status of the tone of the FXS port, enter the following command: NPE> show media tone
- The display will be similar to the following: Media Tones

Index	TDM	Port	VPM	Chan1	VPM	Chan2	DTMF	Detection	Tone	Send	DTMF	Send
0	0		0		1		on		off		off	

Following are descriptions of the information fields:

- port/channel 0/0 Represent the FXS port.
- DTMF detection
 - Reports if DTMF detection is enabled.
- Tone Send
 Reports if the tone is sent out on the FXS port.
- DTMF Send
 Reports if DTMF is sent out on the FXS port.

Show Statistics

The following command displays the statistics of the Jitter Buffer.

- To show the statistics of the Jitter Buffer, enter the following command: NPE> stats voice jitterbuffer
- The display will be similar to the following: Jitter Buffer Stats:

Port Dupl	Frames icated	OverFlow	OutSeq	NullPkts	
	CurrElem	UnderRun	Dropped	LatePkts	
1	0	0	0	0	0
	0	0	0	0	
2	0	0	0	0	0
	0	0	0	0	
3	0	0	0	0	0
	0	0	0	0	
4	0	0	0	0	0
	0	0	0	0	

Following are descriptions of the information fields:

frames

Number of frames played out

- currelem
 Number of elements in the jitter buffer.
- overflow

Number of times jitter buffer overflowed.

- underrun
 Number of times jitter buffer under-runs.
- outseq
 Number of out of sequence packets.
- dropped

Number of dropped packets.

- nullpkts
 Number of null packets.
- latepkts
 Number of late dropped packets.
- duplicated
 Number of duplicate packets dropped.

Configure MGCP UA

Configuring MGCP UA is to define the following:

- How to be authenticated to the MGCP server
- Which CODEC(s) are supported for negotiation purposes
 Up to 4 CODECs can be configured: codec1, codec2, codec3 and codec4. Codec1 is the first preferred choice while codec4 is the last preferred one.
 CODEC can be set to either C 711 a law C 711 a law or C 720 with 10mc or 20mc PTP packs
 - CODEC can be set to either G.711 u-law, G.711 a-law or G.729 with 10ms or 20ms RTP packet interval.
- To activate specific features (RFC 2833 for DTMF, modem pass-through or fax pass-through) depending on the analog device (telephone, modem or fax) connected to the phone port. In the case of a modem, the port can be configured:
 - To not support such device type (MPT OFF)
 - To support such device and force media to G.711 Echo Cancellation (MPT ON)
 - To support such device type and enable re-negotiation of the CODEC with the remote party when modem tone is detected (MPT AUTO).
 - In the case of a fax, the port can be configured as follows:
 - ⁿ To not support such device type (FAX OFF)

To support such device and force media to G.711 Echo Cancellation (FAX CC_ON)

Currently, the following feature is not supported:

Fax T.38

Configuration Requirements

The MGCP Session Controller must be configured. See "Configuring MGCP Session Controller" on page 209.

The MGCP protocol and the FXS port should be configured before setting up the MGCP UA. See "MGCP Protocol" on page 226 and "Configure FXS Port" on page 226.

Configuration Restraints

A codec that configured as NOTUSED will act as a terminator in the preferred codec list; subsequent codecs will be ignored.

For example, if the codec parameters are set as below, codec3 and codec4 will be ignored by ICAD80; they will not be implemented.

codec1 PCMU_10 codec2 NOTUSED codec3 PCMU_20 codec4 PCMA_20

Configuration Commands

NPE> config mgcp ua port

Table 94 describes the parameters for config mgcp ua port.

Parameter	Description
[Port]	A valid FXS interface port number
name	The friendly display name
userID	User ID to form the MGCP Endpoint ID
codec1	The first codec and packet time selection (PCMU_10 PCMU_20 PCMA_10 PCMA_20 G729A_10 G729A_20 NOTUSED)
codec2	The second codec and packet time selection (PCMU_10 PCMU_20 PCMA_10 PCMA_20 G729A_10 G729A_20 NOTUSED)
codec3	The third codec and packet time selection (PCMU_10 PCMU_20 PCMA_10 PCMA_20 G729A_10 G729A_20 NOTUSED)
codec4	The fourth codec and packet time selection (PCMU_10 PCMU_20 PCMA_10 PCMA_20 G729A_10 G729A_20 NOTUSED)
rfc2833	Whether to use RFC2833 for DTMF
payload	RFC2833 payload type (PT)
mpt	Modem pass-through (MPT) (Off On)
fax	Fax Relay mode (Off CC_ON)
up	Whether the MGCP UA port is enabled

Table 94 MGCP User Agent Configuration Parameters

Configure MGCP UA

This example configures the MGCP User Agent for an analog telephone as follows:

Name: uap1 User ID: uap1 RFC2833 DTMF: yes RFC2833 payload type: 96 Enabled: yes

1 Enter the following command:

NPE> config mgcp ua port 1 name uap1 userid uap1 rfc2833 yes payload 96 running

2 To save the configuration, enter: *NPE*> save

Show Configuration

- To show the configuration of the MGCP UA, enter the following command: NPE> show mgcp ua port 1
- The display will be similar to the following:

MGCP User Agent:

Port	Name	Codec1	Codec3	RFC2833	MPT	VAD
	UserID	Codec2	Codec4	Payload	Fax	Running
0-1	7001	pcmu_20	G729A_20	yes	Off	no
	4083747001	pcma_20	NOTUSED	96	Off	no

Show Status

The following command shows the status of the MGCP UA.

- To show the status of the MGCP UA, enter the following command: NPE> show mgcp ua status
- The display will be similar to the following: MGCP UA Ports:

MGCP UA POILS.

Port LineStatus

```
0-1 Inactive
```

Following are descriptions of the information fields

- LineStatus reports the status of the analog device:
 - Idle: the analog device is on-hooked
 - OB (OutBound) Calling: the analog device is off-hooked or a phone number is being dialed
 - OB (OutBound) Proceeding: the remote party rings
 - IB (InBound) Proceeding: the analog device rings
 - Disconnecting: the remote party is disconnected
 - Connected: the analog device is in communication

The following command shows the status of the VoIP communication terminating the MGCP UA.

 To show the status of the VoIP communication terminating the MGCP UA, enter the following command:

NPE> show media stream

 The display will be similar to the following: Media Stream

Index Channel Codec Allocated Codec Used Codec State Connection Packet

Following are descriptions of the information fields:

- index/channel 0/0 Represents the FXS port.
- Codec Allocated
 - Reports the CODEC(s) offered during the MGCP/SDP negotiation.
- Codec Used, Codec State Connection

Report the status of the communication. In this example the connection is started and uses CODEC G.711 u-law.

Show Call Statistics

This section provides references to commands to visualize call statistics. These commands are independent from the Signaling protocol used to establish calls, MGCP or SIP.

Show Commands

NPE> show calls current

Table 95 describes the information displayed by show calls current.

Parameter	Description
aname	A Party name identifier
anumber	A Party number (if known)
bname	B Party name identifier
bnumber	B Party number (if known)
type	Where the call is originating from
state	Current state of the call
protocol	What protocol the calling party is using
quality	RTCP-XR derived MOS quality scores (MOS-LQ/MOS-CQ)
starttime	Start time of the call
duration	Time elapsed since start of the call

Table 95 Current Calls

NPE> show calls history

Table 96 describes the information displayed by show calls history.

Parameter	Description
aname	A Party name identifier
anumber	A Party number (if known)
bname	B Party name identifier
bnumber	B Party number (if known)
type	Where the call is originating from
state	Current state of the call
protocol	What protocol the calling party is using
quality	RTCP-XR derived MOS quality scores (MOS-LQ/MOS-CQ)
starttime	Start time of the call
duration	Time elapsed since start of the call

Table 96 Call History

Show Current calls

- To show the current calls, enter the following command: NPE> show calls current
- The display will be similar to the following:

Call List:

A Party	B Party	Type	Protocol	Sta	art	Time	
A Number	B Number	State	Quality	Du:	rat	ion	
Sophia 6017	6016,Sophia	Outbound	MGCP	FEB	24	03:24:24	2006
6017	6016	Connected	4.20/4.18	13	se	conds	

Following are descriptions of the information fields:

Type

Reports if the call is originated from LAN (OutBound) of from WAN (InBound).

State

Reports the state of the call:

- Proceeding: the call is in progress
- Connected: the call is established
- Failed: the call terminated abnormally
- Succeed: the call terminated normally

The field Quality reports the quality of the stream coming from WAN. It reports a MOS. In the case the CODEC used is not supported by Voice Quality Monitoring (see "Voice Quality Monitoring (VQM)" on page 221) or no RTP traffic is received, this field reports "Not measured".

Show Call History

- To show the call history, enter the following command: NPE> show calls history
- The display will be similar to the following:

Call History:

A Party	B Party	Type	Protocol	Start Time
A Number	B Number	State	Quality	Duration
Sophia 6017	6016,Sophia	Outbound	MGCP	FEB 24 03:24:24 2006
6017	6016	Succeed	4.20/4.18	13 seconds

Following are descriptions of the information fields

- History can be filled with up to 250 entries. It is filled in a FIFO mode; the last call is inserted at the end.
- The fields are the same as described in "Show Current calls" on page 233.

Configuring MGCP Endpoints

This section provides guidelines to configure MGCP endpoints located in LAN.

For a MGCP endpoint to place and receive calls, the following are required:

- The MGCP endpoint must be allowed by Access Control List (ACL).
- The MGCP endpoint must be registered to the MGCP server through the MGCP SC.
- The MGCP UA must be considered as a normal MGCP endpoint located in LAN.

Access Control List (ACL)

To configure Access Control List, refer to "Access Control List (ACL)" on page 215.

For the MGCP UA Access Control List does not need to be configured. The MGCP UA is automatically allowed to place and receive calls. It cannot be disallowed.

Registration

The MGCP endpoints need to be registered to the MGCP server through the MGCP SC using the MGCP method RSIP.

To make this happen, the MGCP endpoints must be configured as following:

- MGCP endpoint identification must be per MAC address.
- MGCP Call Agent must be the LAN IP address of the ICAD80.
- MGCP Call Agent port must be the one configured to the one configured in the MGCP SC (LAN Rx port).

For information for a Cisco MGCP phone 7960, firmware POM3-07-5-00, the following configuration would be required (interactive menu or text configuration file):

- use_mac_name: 1 (enabled)
- mgcp_gw_controller: LAN IP address of the IACAD40
- mgcp_output_port: LAN RX port of the MGCP SC

When the phone is correctly registered, it is reported by the command show ${\tt mgcp\ sc\ endpoints}$. An example follows.

MGCP Session Controller	endpoints:		
Endpoint ID	EP Addr	EP Port	Act Calls
Endpoint Name	TelNo	CA Port	Timeout
4083746017@00152b177677	10.0.1.57	2427	0
Sophia 6017	6017	2432	3436

To configure the registration of the MGCP UA refer to "Configuring MGCP User Agent" on page 225. The command show mgcp sc endpoints would report the following when it gets successfully registered to the MGCP server.

MGCP Session Controller endpoints:

Endpoint ID	EP Addr	EP Port	Act Calls
Endpoint Name	TelNo	Lan Domain	Timeout
4083747001@001111111111	127.0.0.1	2429 2429 2429	0 3434

The information that identifies the MGCP UA is $\tt AP_Addr$, which is set to the loopback IP address 127.0.0.1.

12 VOIP SURVIVABILITY

This chapter provides information about VoIP survivability: LCR configuration for SIP and MGCP signaling protocols; lifeline failover for power outage.

Introduction

This section provides guidelines for configuring the ICAD80 for local call routing (LCR), also known as VoIP Survivability, which supports the following features:

- Ensures emergency calls are routed to the external voice network
- Ensures local calls

Local Call Routing

When the VoIP service is unreachable, LAN endpoints normally cannot make calls; they cannot reach destinations on either the LAN or the WAN. This may occur in the following scenarios:

- The VoIP server is unreachable from the ICAD80
 Signaling packets cannot be sent to the VoIP server.
- The VoIP service goes down
 Calls are sent out, but calls/replies cannot be received. If one server is available, failover can be used to continue operation. See page 172 for SIP failover mode, and page 208 for MGCP failover mode. However if all servers are down, VoIP service will be unavailable.

When VoIP service is unreachable, the ICAD80 switches to LCR mode. Calls originated from LAN VoIP phones or from the Integrated User Agent can still be routed to another VoIP phone, an Integrated User Agent, or the PSTN through the FXO port or the SIP gateway. When LCR takes place, only basic telephone services are supported.

- Local calls (between LAN endpoints) are established through the ICAD80, acting as a VoIP server (SIP server or MGCP Call Agent).
- Calls identified as external calls are routed to PSTN through the FXO interface of the ICAD80, or through a SIP/PSTN gateway located in the LAN.

When a VoIP server is again reachable and available, the ICAD80 returns to the normal (VoIP) mode for calls.

Lifeline Failover

Should the ICAD80 lose power, all FXS ports are physically switched to one FX0 port; this allows receiving and sending external calls.

When power is down, the ICAD80 is non-operational; functions such as VoIP and QoS configurations are not supported.

Local Call Routing

This section provides guidelines for configuring Local Call Routing.

Configuration Requirements

SIP or MGCP Session Controllers must be configured. For SIP, see Chapter 10, "SIP Configuration". For MGCP, see Chapter 11, "MGCP Configuration".

Configuration Main Menu

NPE> config lcr accounts

Table 97 describes the parameters of config lcr accounts.

Table 97	LCR	Configu	ration	Main	Menu
----------	-----	---------	--------	------	------

Parameter	Description
[dn]	Dial Number of the account
type	Type of the account (SIP MGCP)
id	ID of the account

The CLI command lcr accounts informs ICAD80 the location of a local endpoint, when the user ID /endpoint ID does not contain information about the telephone number. For example, when a SIP account is defined by a name string, this command tells the ICAD80 the telephone number of that account.

NPE> config lcr settings

Table 98 describes the parameters of config lcr settings.

_	
Parameter	Description
lcbmode	Local Call Backup Mode (INT LGW)
ecnumber	Emergency Call Number
obaccess	Outbound access digit
areacode	Area code of this installation
coprefix	Central Office Prefix of this installation
enlength	Extension Number Length

Table 98 LCR Configuration Main Menu

Following are details of the parameter:

lcbmode

How to route an external call: specifies is external calls are established through the FXO port of the ICAD80 (INT) or through a VoIP/PSTN gateway (LGW) co-located on the LAN.

MCGCP gateways are not supported.

ecnumber

Emergency number, at the installation location, used by session controller. ecnumber is used to route the emergency call externally. This parameter can also be used to assure bandwidth during normal operations (non-LCR).

obaccess, areacode, coprefix, enlength

Number information about the location; identifies if a dialed number is destined for a local endpoint. These parameters should be set to accurately reflect the number plan; when VoIP is available, using an outbound number makes an outside call (obaccess), and/or automatically checking the first digits for an internal call (enlength) when an outbound number is not entered by the caller.

- obacess only applies for hosted PBS service. In this situation, outbound calls are provided by dialing an outbound prefix, such as 9 555 1212. Otherwise, leave this value blank.
- areacode, coprefix, and enlength define a complete telephone number plan, specified for local accounts. For example: 408 374 1001.
 - 408 indicates areacode
 - 374 indicates prefix
 - 1001 indicates external subscriber
 - All this parameters should be used; they help LCR identify if a telephone number is a local endpoint. A configuration example is proved in "Example 2" on page 240.

Configure LCR Accounts

Configuring LCR accounts is not always required.

LCR accounts are not required if the IDs of the LAN endpoints are numbers.

LCR accounts are needed if the IDs of the LAN endpoints are alphanumeric. In this case, to contact the LAN endpoints, the ICAD80 (acting as a VoIP server) needs to know the telephone numbers of the endpoints.

If not configured, only VoIP phones that allow entering alphanumeric IDs can place calls, not other entities, such as the User Agent.

This example creates an entry as follows:

Phone number: 5555 (dial four digits to connect to an office telephone: local endpoint) SIP ID: call.five

1 Enter the following command:

NPE> config lcr accounts 5555 type SIP id call.five

2 To save the configuration, enter:

NPE> save

Configure LCR Settings

Configuring the LCR settings is only required to make calls through the FXO port of the ICAD80 or through a SIP VoIP/LAN gateway located in LAN.

The advantage of the latter solution (via gateway in LAN) is multiple calls can be active, whereas in the first case (via FXO port), only one call can be active.

Example 1

The following example configures the FXO port to handle emergency calls.

- 1 Enter the following command: NPE> config lcr settings lcbmode INT
- 2 To save the configuration, enter:

NPE> save

Example 2

The following example uses the prefix "9" for outbound calls. The setup is as follows:

prefix for outbound calls: 9 area code: 408 company office prefix: 374

length of extension number: 4

1 Enter the following command:

NPE> config clr settings obaccess 9 areacode 408 coprefix 374 enlength 4

2 To save the configuration, enter:

NPE> save

This configuration will support calls as follows:

Number dialed Action

- 2210 4-digit call, check local accounts only
- 9411 outbound call for 411
- 93742210 check local accounts only for 2210
- 96872210 route 6872210 to PSTN
- 914083472210 check local accounts only for 2210
- 914086872210 route 14086872210 to PSTN

Show Configuration

- To show the results of the LCR account configuration, enter the following command: NPE> show lcr accounts
- The display will be similar to the following:

LCR Accounts: DN	Туре	ID
2222	SIP	call.two
5555	SIP	call.five

- To show the results of the LCR settings, enter the following command: NPE> show lcr settings
- The display will be similar to the following: LCR Settings:

LCBMode	ECNumber	OBAccess	AreaCode	COPrefix	ENLength
INT	911	9			4

Show Status

The Session Controller either runs in normal mode (all calls are established through a VoIP server) or in LCR mode (local calls and emergency calls are handled by the ICAD80, acting as a VoIP server; other calls are rejected).

- To show the status of the LCR mode, enter the following command (example for SIP):
 NPE> show sip sc status
- The display will be similar to the following: SIP Session Controller status:

SSC Started	Yes
SSC Server Ready	No
My Wan IpAddr	0.0.0.0
Wan Rx Port	5060
Lan Rx Port	5060
CAC Max Calls	500

Following are descriptions of the information fields

SSC Server Ready
 Variat Session Controller runs

Yes: Session Controller runs in normal mode. No: Session Controller runs in LCR mode.

Show Connections

- To show the connections established in LCR mode, enter the following command: NPE> show lcr connection
- The display will be similar to the following: Connection List:

Caller	Called	То	Туре
call.two	call.five	5555	Internal

Following are descriptions of the information fields:

Caller, Called

The Identifiers of the source and destination of the call, respectively.

To

The phone number that was called.

• Туре

Reports if the call is established between two LAN endpoints or between a LAN endpoint and the PSTN. Note that a LAN endpoint can also be the Integrated User Agent.

Lifeline Failover

If the ICAD80 loses power, all FXS ports are physically switched to one FX0 port; this allows receiving and sending external calls, including emergency calls.

When power is down, all 16 FXS ports are connected to one FXO port; on the breakout box, ports 1-16 (FXS) will be physically connected to port 17 (FXO). This connectivity creates a *party line*.

- Only one FXS port can dial out or receive a direct call
- When one FXS port is connected to an outside call, all other FXS ports can access that connection

Figure 6 illustrates lifeline failover connectivity.



Figure 6 Power Failure

If power failure occurs, the ICAD80 will automatically use the FXO lifeline to route calls from the FXS ports directly to PSTN.



This appendix provides information for upgrading ICAD80 software.

Introduction

The software that can be upgraded or re-installed in a ICAD80 are the application (image) and the bootloader code. This process is supported by Web UI, a feature of ICAD80.

For more information about Web UI, see Appendix B, "Web UI".

Check Boot Code

It is recommended to check the current version of bootloader code in the ICAD80. At the release of this document, version 9 (X.XX.0009) or greater should be used when upgrading software. For instructions to check the version of bootloader code, see "View Bootloader Code" on page 306.

If the bootloader code must be upgraded, see "Upgrading Software Via Web UI" on page 303.

7	able	144	File	Names
	unic	177	1 110	numes

File Type	File Name
Image	app.bin
Bootloader	boot.bin

Images

Two images can be stored in ICAD80 in locations slot 1 and slot 2 on the compact flash. This feature allows you to save an image when upgrading the application software.

Only one image can be primary (default): the image that is used to run ICAD80. The other image is secondary: an alternate image that you can select to run, should it be necessary. For instructions to select which image is default, see "Change Default Application Image" on page 306.

Upgrading Software Via Web UI

This section provides instructions to upgrade the application or bootloader software of the ICAD80. Your workstation can access the ICAD80 through the Internet or a LAN connection.

This procedure assumes the ICAD80 has been physically installed in the network and is operational.

Requirements

- The Internet browser on your workstation must be either Microsoft Internet Explorer or Mozilla FireFox.
- The IP address of the ICAD80 must be known.
- The name of the upgrade software file must be known.

 The location of the file must be known. e.g., it must be available at a known location on your workstation.

To acquire the upgrade software, contact your IT manager or Customer Support.

The instructions follow.

Upgrade Software via Web UI

Login

- 1 Enter the IP address of the ICAD80 on the web browser, which can be done via HTTP or HTTPS:
- HTTP

Enter the IP address using http: http://xxx.xxx.xxx

HTTPS

Enter the IP address using https:

```
https://xxx.xxx.xxx.xxx
```

The login window opens, requesting your user name and password. See Figure 7.

Figure 7 Web UI Login Window

2 Enter your user name and password in the appropriate text boxes: Name, Password. The default name is admin.

The default password is admin.

NOTE: The password is case sensitive.

3 Press the Login button.

WEB UI opens with the System Screen, which shows current system statistics.



Figure 8 Default Window after Login

4 Logging in is complete.

Upgrade Software

5 Under the configuration menu, select upgrade. See Figure 9.

	•			 	0	2	
System					0		
System Status Overview Services User Accounts DHCP Server Radius SNMP SBL Upgrade (h) Configuration License Logging Information Logging Modules	System >> Upgrade Software Select an image to upgrade Solot 1 Solot 2 Bootloader Load File: Upgrade Application image to boot fi Slot Defau 1 0 2 0 Apply	(Browse,	[empty] [empty] Detail [empty] [empty]				

Figure 9 Upgrade Image

- 6 In the Upgrade tab, select which image (slot) to upgrade:
 - ⁿ Slot 1 and Slot 2 represent the application software (images) that are present on ICAD80.
 - The image (slot) that is upgraded is automatically set as the (default) image the ICAD80 runs on. After installation, the default image can be changed. (Refer to "Change Default Application Image" on page 306.)
 - **Bootloader** represents the application that loads in the new image.
- 7 In the Load File text box, select the file to upload.

If necessary, use *Browse* to locate the file.

8 Click the Upgrade button.

```
Several messages will display.
```

When the upgrade is complete the message Updated will appear.

9 To complete the upgrade, reboot the ICAD80. To do so, select the Reset System button under Operations. See Figure 10.

IMPORTANT: Do not reboot the ICAD80 until after the Updated message is displayed.

Operations	
Log Out	
Save System	
Reset System	Reset Syste

Figure 10 Reset System

10 Upgrading the software is complete.

NOTE: When the ICAD80 reboots, the Internet connection will be lost.

To re-connect to the unit, you will have to login. See "Login" on page 304.

11 It is recommended to verify the software was successfully installed. See "Verify Software Installation" on page 306.

Verify Software Installation

- 1 If you are already logged in, proceed to the next step. Otherwise, login to the ICAD80 through the Web UI. See "Login" on page 304.
- 2 On the menu bar, select System. See Figure 11.

MyUnit 192.168.15.136	System	Data	Quality	Security	Voice	Monitor	Wizards
	40						

Figure 11 Menu Bar

- 3 Under the configuration menu, select Upgrade. See Figure 9 on page 305.
- 4 Under the section Application image to boot from:, the current image files will be listed under Detail.

Under **Default**, the highlighted button indicates which image is set for default.

5 This procedure is complete.

Change Default Application Image

- 1 If you are already logged in, proceed to the next step. Otherwise, login to the ICAD80 through the Web UI. See "Login" on page 304.
- 2 On the menu bar, select System. See Figure 11 on page 306.
- 3 Under the configuration menu, select Upgrade. See Figure 9 on page 305.
- 4 Under the section Application image to boot from:, select the desired image for default. To do so, select the appropriate button under default. See Figure 9 on page 305.
- 5 Select the button Apply.
- 6 This procedure is complete.

View Bootloader Code

1 If you are already logged in, proceed to the next step. Otherwise, login to the ICAD80 through the Web UI. See "Login" on page 304.

- 2 On the menu bar, select System. See Figure 11 on page 306.
- 3 Under the configuration menu, select Overview. See Figure 9 on page 305.
 - The System Information section will show the version of the bootloader software.
 - The version of the default application will also be displayed.

	System Informa	tion			Shell:	
	Unit Name	Ren	a		Width	80
ootloader code —	Bootcode Ver	1,1(0.00	09	Promp	t Rena
pplication	App. Ver	ICA	D T2	2.02.0181	Timeou	rt (min)
	System Type	NP8	0			
	Memory	82/:	128	MB		
	Country	United States of America (US)				
	Up time	1 day, 22 hours, 7 mins & 10 secs			O Modify	
	🔘 Modify					
	System Hardwar	ne D	7.0			cl :-
	Board DTD/0	Re	v 11	Description	O I II (NDE)	Chip
	DIVG	1	1	vata relephony video	Controller (NPE)	FUSIV-200
	TEL	0				
	TEL	0	2	16 FAS + 2 FAU		BCM

Figure 12 Software System Overview

4 This procedure is complete.

Find IP Address via CLI

This procedure assumes the following:

- Your PC is connected to the CONSOLE port of the ICAD80 through a serial port cable
- Tera Term Pro, or a similar terminal emulator, is running on your PC.

NOTE: This procedure uses Tera Term Pro.

For information about third-party software, see Appendix C, "Third Party Software".

- 1 On the PC, connect to the ICAD80 through the terminal simulator. See Figure 13.
 - a Select File, and then, New Connection from the menu bar.
 - b In the window that opens, *Tera Term: New Connection,* select the Serial button.
 - c Select the appropriate COM Port.
 - d Click OK.
| C ICP/IP | H <u>o</u> st: | myhost.mydomain - |
|----------|----------------|-------------------|
| | | |
| Serial | Port: | COM1 - |

Figure 13 Connect to ICAD80

- 2 The monitor will display the following: User:
- 3 Enter the default user name: admin. The response will be as follows:

Password:

- 4 Enter the default password: admin.
 The prompt will appear: NPE>
 NOTE: The prompt may after system information has been displayed.
- 5 Enter the following command:

NPE> show interface IP

6 The display will be similar to the following:

"eth0" info: [WAN Port]

	Interface	eth0
	Flags	(A843) < UP BROADCAST RUNNING SIMPLEX LINKUP
MUI	LTICAST >	
	IP Address/Mask	172.16.1.217/255.255.255.0
	MTU	1500
	DHCP	off
	Lease obtained	N/A
	Lease expires	N/A
	MAC Address	00:15:93:FF:00:F8
	Speed	AUTONEG

"eth1" info: [LAN PORT]

Interface	ethl
Flags	(A843) < UP BROADCAST RUNNING SIMPLEX LINKUP
MULTICAST >	
IP Address/Mask	192.168.1.1/255.255.255.0
MTU	1500
DHCP	off
Lease obtained	N/A
Lease expires	N/A
MAC Address	00:15:93:FF:00:F9
Speed	N/

"fr0" info: [T1 WAN PORT]

Interface

Flags	(20C1) < UP RUNNING NOARP LINKUP >
IP Address/Mask	10.12.0.1/255.255.255.0
MTU	4096
DHCP	off
MAC Address	00:00:00:00:00:00
Speed	N/A

- 7 This procedure is complete.
- If connecting to the ICAD80 through the WAN port, use the eth0 or the T1 address.
- If connecting to the ICAD80 through a LAN port, use the eth1 address.

L INDEX

Α

access control 61 Access Control List. See ACL account add user 62 remove group 66 remove user 65 ACL 163, 195 authentication 164, 196 configure 195 **SIP UA 183** Acrobat Reader 311 add **ARL** 105 group 64 static route 95 address forwarding NAT 128 address learning process 105 Address Resolution Logic. See ARL Address Resolution Protocol. See ARP admin default password 62 admin accounts default setting 41 admin groups default setting 41 admin rights default setting 42 aging time 105 alarm

frame relay 74 LEDs 73 ALG configure 132 ALL 54 Application Layer Gateway. See ALG ARL add 105 add entry 105 aging time 105 configure 105 entries 105 flush 107 remove 107 remove entry 107 ARP configure 93 delete 94 flush table 95 subnetwork 93 table 93 audit logging configure 257 authentication 241 ACL 164, 196 **RADIUS client 241** user management 61 authenticationfail 276 auto download files 251 automatic mode SIP server 152 B back pressure 100 bandwidth control, GoS 438 BE 439 Best Effort. See BE С CAC configure 199 maximum calls 201 OoS 199 cache delete TFTP 252 file 250 **TFTP 251** Call Admission Control. See CAC call history 182 call server keep-alive 186

CAR 145 CDP configure 284 CDP packets monitor 284 change password 67 check DNS client 88 Cisco Discovery Protocol. See CDP classification 438 CLI auto run command 59 command groups 49 command keyword all 54 custom help 50 debug help 51 debug commands 48, 49 help <tab> 50 ? 50 specific 50 interactive mode 53 keyword no 53 maintenance commands 47, 49 help 51 on-line help 47 prefixes 49 save configuration 59 syntax 52 valid prefixes 50 variables 50 client **DNS 87** CODEC MGCP VQM 202 VQM 169 coldstart 276 configuration dump 54 save 59 configure ACL 195 ALG 132 ARP 93 ARP flush table 95 audit logging 257 CAC 199 CDP 284 DHCP relay 246 DHCP server 243

DNS client 87 DNS relay 246 dynamic routing 96 file system 225 firewall 118 firewall (security policies) 118 FxS port 206 host keys, regenerate 229 IDS 121 IDS anomaly 122 IDS flood 123 IDS scan 124 IDS spoof 125 interface eth0 71 eth1 70 NAT 129 vlan 81 LCR accounts 219 LCR settings 219 LMI 77 logging destination 261 logging level 259 MBR 193 MCGP MSP 190 MGCP ACL 214 MGCP endpoints 214 MGCP fail-over 188 MGCP server 187 MGCP session controller 189 MGCP UA 209 MGCP user agent 205 MGCP VQM 201 NAT 128 address forwarding 130 port forwarding 130 static 131 NAT interface 129 NAT policy 129 NAT port forwarding 133 NAT public 131 netflow 273 permanent virtual circuit 74 port mirroring 107 QoS 138 DiffServ/ToS 111 IEEE 802.1p 111 port 111 priority 112 traffic classification 143 QoS layer 2 109 QoS quality group 141 QoS traffic classification 142

QoS type 112 quality groups 139 RADIUS client 241 routing table 95 security NAT 133 SIP additional servers 153 SIP ACL 163 SIP CAC 166 SIP endpoints 183 SIP fail-over 152 SIP load balance 153 SIP Media BRidge (MBR) 161 SIP server 151 SIP session controller 156 SIP SSP 157 **SIP VOM 168 SNMP** 276 SNMP trap 279 SNTP relay 248 SNTP time 87 SSH host keys 232 SSH server 231 SSL certificate 235 **SSL CSR 235** SSL key 235 static route delete 96 static routing 95 telnet server 224, 230, 231, 238, 240, 246, 247, 248 TFTP cache 250, 251 TFTP relay 249 time 85 **VLAN** 112 LAN 114 WAN 114 VLAN interface 80 WAN port 102 watchdog 89 web server 233, 237 **Configuring** 71 **Connection Protocol** 313 connection timeout 120 console logging destination 261 **CSR** 234 customer support hardware system 90 D debug

system exceptions 89

debug commands syntax 52 default password admin 62 user 62 default setting admin accounts 41 admin rights 42 admins group 41 disabled 45 enabled 44 eth0 41 eth1 41 IP interface 41 LAN port 100 media 43 QoS layer 2 44 security policies 42 security policy LAN to ICAD40 42 LAN to WAN 42 telnet WAN to ICAD40 43 Web UI LAN to WAN 43 Web UI WAN to ICAD40 43 ssh/sfpt 44 telnet 44 user accounts 41, 42 user group 41 userbasic rights 42 voice ACL 43 voice parameters 42 WAN port 103 web server management 44 delete ARP entry 94 TFTP cache 252 DHCP eth0 interface 71 option 42 248 option 6 247 option 66 249 DNS primary server 88 DNS client check 88 configure 87 documentation feedback 2 DSA host keys 228, 232 regenerate 232 dump show configuration 54 dynamic routing

configure 96 Ε Endpoint Status Handling. See ESH ESH 165 SIP 165 eth0 default setting 41 **DHCP** 71 eth1 default setting 41 exception system 256 system error 90 exceptions system 89 F fail-over MGCP server 188 SIP server 152 failover lifeline 221 feedback, documentation 2 file cache 250 logging destination 262 file system management 225 firewall connection timeout 120 remove 120 rules 119 security policies 118 flow control back pressure 100 LAN 100 pause frames 100 QoS 100 QoS constraints 110 WAN 103 flush ARL 107 ARP table 95 forwarding database remove ARL 107 frame relay LMI 77 front port 99 FTP download files 251 FxS port 206

G

GoS 435 classification 438 multiplexing 439 policing 438 processes 437 GoS classes 138 group add 64 remove 66 Guarantee of Service. See GoS н hardware monitor 255 history call 182 http connection timeout 121 L ICAD40 connectivity 41 description 40 ICMP statistics 266 IDS anomaly 121, 122 clear statistics 127 configure 121 flood 121, 123 log 128 scan 121, 124 spoof 121, 125 statistics 125 IEEE 802.1p QoS priority queue 109 Interface eth1 70 WAN 71 interface eth0 71 LAN 70 lan 70 NAT 129 **VLAN 80** WAN 71 internal logging destination 262 intrusion detection service. See IDS IP connectivity services 239

default settings 41 routing stack 264 stack statistics 264 IP address **VLAN 80** IP host uplink 99 Κ keep-alive **MGCP** 186 keepalive 190 key **CSR** 234 **DSA** 228 DSA host 232 upload public 229, 233 L LAN ARL 105 port mirroring 108 VLAN 114 LAN port default settings 100 statistics 102 LCR 217 accounts 219 settings 219 I FD loss of carrier 73 loss of synchronization 73 master mode 73 slave mode 73 lifeline failover 221 link QoS 138 linkdown 276 linkup 276 LMI 77 Load Balance SIP 153 Local Call Routing. See LCR Local management interface. See LMI log IDS 128 logging map 260 system security 257 logging destination configure 261 logical links **MGCP** 185

login default password admin 62 user 62 Μ MAC address ACL 164 ARL 105 learning process 105 maintenance commands syntax 52 management GoS 436 manual mode SIP server 152 map ARL 105 MBR configure 193 status 194 Media 185 media default setting 43 Media BRidge (MBR) 161 Media Gateway Control Protocol. See MGCP messages syslog server 262 MGCP keep-alive 186, 190 relay headers 190 server priorities 187 services 186 session controller 186, 189 signalling messages 190 signalling proxy 190 statistics 201 user agent 186 VOM 201 MGCP Signaling Proxy. See MSP MGPC protocol 206 mii port 99 mii0 WAN port 102 monitor CDP packets 284 customer support 255 logging level 259 MGCP voice quality 202

netflow 273 operation details 258 operation errors 258 operation information 258 **PMON 270 SNMP** 276 system exception 256 system hardware 255 system information 256 system module 258 system operations 257 voice quality 284 **MSP** 190 multiplexing GoS 439 Ν NAT address forwarding 128 configure 128 configure address forwarding 134 configure security 133 policy 129 port forwarding 128 reverse 128 standard 128 static 128 WAN interface 129 netflow configure 273 monitor 273 reported information 273 network discovery 284 vlan 69 Network Address Translation. See NAT NO 53 Ρ password change 67 pause frames 100 permanent viritual circuit configure 74 ping 239 DNS client 88 PMON monitor 270 statistics 272 policy NAT 129 port 0 - 4 99

front 99 FxS 206 LAN clear statistics 102 flow control 100 mode 99 speed 99 statistics 102 mii 99 mirror 107 **VLAN** 112 WAN configure 102 flow control 103 mii0 102 mode 103 speed 103 statistics 104 port forwarding NAT 128 port mirroring configure 107 LAN 108 remove 109 port number QoS priority queue 109 priority queues IEEE 802.1p 109 port 109 routing 109 priority queues 109 protcol connection 313 protocol **MGCP 206** Transport Layer 313 user authentication 313 Protocol Monitoring. See PMON PVC see permanent virtual circuit 74 Q QoS BE (best effort) 139 best effort link capacity 139 CAC 199 CAR 145 class values 140 configure 138

configure link 138

cumulative statistics 144 DiffServ/ToS 111 flow control 100, 110 GoS classes 138 IEEE 802.1p 109 instantaneous statistics 146 laver 2 109 links 138 model matrix, GoS 439 policing 138 port number 109 priority gueues 109 quality groups 138, 139 quality guaranteed class 140 remove group 142 remove link 139 remove traffic classification 144 security policies 138 statistics 144 ToS/DiffServ 110 traffic classification 138, 143 traffic flow 142 type 112 **IEEE** 111 port 111 setting 110 voice traffic 137 QoS layer 2 default setting 44 quality groups QoS 139 quality guaranteed class QoS 140 R **RADIUS** client 241 registration SIP 183 relav **DHCP** 246 **DNS 246 SNTP 248 TFTP 249** TFTP cache 250 remove ARL 107 mirroring 109 QoS group 142 QoS link 139 QoS traffic classification 144 **VLAN** 115 reverse NAT 128

rights user 64 RIP ICAD40 support 96 routing dynamic 96 priority 109 static 95 traffic interfaces 69 rules firewall 119 S security policies default setting 42 Security Policies. See firewall server **DHCP** 243 primary, DNS 88 **SFTP 227** SSH 231 telnet 230 web 233 servers SIP additional servers 153 service authentication 241 VoIP phone 243 web UI 224, 230, 231, 238, 240, 246, 247, 248 session controller keep-alive 186 MGCP 186, 189 SIP 150 Session Initiation Protocol. See SIP SFTP SSH 227 SHA 62 SIP ACL 163 CAC 166 concurrent calls 150 configure server 151 endpoints 183 ESH 165 load balance 153 Media BRidge 161 media connection 163 overwrite media 150 registration 183 relay messages 150 server

automatic mode 152 manual mode 152 session controller 150, 156 SSP 157 terminal accounts 150 user agent 150 VQM 168 SIP Signalling Proxy. See SSP **SNMP** traps 276, 279 SNMP agent 276 SNTP relay 248 time 85 sntp time modify 87 SSH internet access 313 SSH-AUTH] 313 SSH-CONNECT 313 SSH-TRANS 313 SSL certificate 235 certificate signing request 234 web server 233 SSL certificate configure 235 SSL connection SSL CSR 234 SSL key 234 SSL CSR configure 235 upload 237 SSL key configure 235 standard NAT 128 static NAT 128 static route add 95 delete 96 static routing configure 95 statistic QoS instantaneous 146 statistics call 181 clear WAN port 105

clear IDS 127 **ICMP 266** IDS 125 IP stack 264 LAN clear 102 LAN port 102 **MGCP** 201 MGCP call quality 204 MGCP logging internal 204 MGCP packets 191 MGCP SC calls 192 MGCP voice quality 203 netflow 275 **PMON 272** QoS 144 QoS cumulative 144 SIP packets 159 SIP SC calls 162 SIP voice quality 170 **TCP** 268 **UDP** 267 WAN port 104 status FxS port 208 **MBR** 194 **SIP MBR 162** summary system operations 263 syslog emergency message 261 logging destination 262 server messages 262 system exceptions 89 hardware 90 operations summary 263 system crash 256 system error show exceptions 90 system exception monitor 256 system hardware monitor 255 system information monitor 256 system module log 258 system operations monitor 257

system security logging 257 т table **ARP** 93 TCP statistics 268 tcp connection timeout 121 telnet client 230 open session 231 server 230 Tera Term Pro 311 TFTP cache 250 configure cache 251 download files 251 server 248, 249 TFTP relay 249 time modify 87 SNTP client 85 timeout connection 120 ToS/DiffServ QoS priority queue 110 traceroute 240 traffic best effort (QoS) 139 classification (QoS) 143 contention 137 filter netflow 273 **ICMP 266** IP stack 264 TCP 268 trace 270 voice 137 traffic classification 118, 142 traffic flow quality groups 142 Transport Layer Protocol 313 trapmib 280 U UDP logging destination 262 statistics 267 uplink IP host LAN 99 IP host WAN 102

mirror traffic constraint 108 port features 99 user active 67 default password 62 remove account 65 remove rights 66 rights 64 user accounts default setting 42 default settings 41 user agent MGCP 186, 205 SIP 150 User Authentication Protocol 313 user groups default setting 41 userbasic rights default setting 42 V vid **VLAN** 113 VLAN configure 112 ID 113 LAN 114 name 113 port 112 remove 115 route traffic 80 trunking 113 vid 113 WAN 114 voice ACL default setting 43 voice parameters default setting 42 voice quality monitor 284 Voice Quality Monitoring. See VQM **VQM** 168 CODECs 169 MGCP 201 MGCP CODEC 202W WAN clear statistics 105 default setting 103 **VLAN** 114 WAN port

statistics 104 warmstart 276 watchdog configure 89 web server configure 237 X X509 CSR 234